



Service Manual

MODELS: GWH09RB-K3DNA2C(CB301001100)
GWH09RB-K3DNA2C(CB301001102)
GWH09RB-K3DNA3C(CB302000900)
GWH09RB-K3DNA3C(CB302000901)
GWH09RB-K3DNA5C(CB304000500)
GWH09RB-K3DNA6C(CB305000100)
GWH09RB-K3DNA8C(CB313000100)
GWH12RB-K3DNA2C(CB301001200)
GWH12RB-K3DNA2C(CB301001202)
GWH12RB-K3DNA3C(CB302001000)
GWH12RB-K3DNA3C(CB302001001)
GWH12RB-K3DNA5C(CB304000600)
GWH12RB-K3DNA6C(CB305000200)
GWH12RB-K3DNA8C(CB313000200)
(Refrigerant R410A)

Table of Contents

Summary and Features	1
1. Safety Precautions	3
2. Specifications	4
2.1 Unit Specifications	4
2.2 Operation Characteristic Curve	12
2.3 Capacity Variation Ratio According to Temperature	12
2.4 Operation Data	13
2.5 Noise Criteria Curve Tables for Both Models	13
3. Construction Views	14
3.1 Indoor Unit	14
3.2 Outdoor Unit	14
4. Refrigerant System Diagram	17
5. Schematic Diagram	18
5.1 Electrical Wiring	18
5.2 Printed Circuit Board	20
6. Function and Control	22
6.1 Remote Control Operations	22
6.2 Description of Each Control Operation	26
7. Installation Manual	31
7.1 Notices for Installation	31
7.2 Installation Dimension Diagram	33
7.3 Install Indoor Unit	34
7.4 Install Outdoor Unit	35
7.5 Check after Installation and Test Operation	36
7.6 Installation and Maintenance of Healthy Filter	37

8. Exploded Views and Parts List	38
8.1 Indoor Unit.....	38
8.2 Outdoor Unit.....	46
9. Troubleshooting	50
9.1 Malfunction Analysis.....	50
9.2 Flashing LED of Indoor/Outdoor Unit and Primary Judgement.....	54
10. Removal Procedure	72
10.1 Removal Procedure of Indoor Unit.....	72
10.2 Removal Procedure of Outdoor Unit.....	77


Summary and Features

Indoor Unit


GWH09RB-K3DNA2C/I(CB301N01100)
GWH09RB-K3DNA2C/I(CB301N01101)
GWH12RB-K3DNA2C/I(CB301N01200)
GWH12RB-K3DNA2C/I(CB301N01201)




GWH09RB-K3DNA3C/I(CB302N00900)
GWH09RB-K3DNA3C/I(CB302N00901)
GWH12RB-K3DNA3C/I(CB302N01000)
GWH12RB-K3DNA3C/I(CB302N01001)



GWH09RB-K3DNA5C/I(CB304N00500)
GWH12RB-K3DNA5C/I(CB304N00600)



GWH09RB-K3DNA6C/I(CB305N00100)
GWH12RB-K3DNA6C/I(CB305N00200)




GWH09RB-K3DNA8C/I(CB313N00100)
GWH12RB-K3DNA8C/I(CB313N00200)




Outdoor Unit


GWH09RB-K3DNA3C/O(CB302W00900)




GWH09RB-K3DNA3C/O(CB302W00901)



GWH12RB-K3DNA3C/O(CB302W01000)



GWH12RB-K3DNA3C/O(CB302W01001)



Remote Controller

YAA1FB



1. Safety Precautions

Installing, starting up, and servicing air conditioner can be hazardous due to system pressure, electrical components, and equipment location, etc.

Only trained, qualified installers and service personnel are allowed to install, start-up, and service this equipment. Untrained personnel can perform basic maintenance functions such as cleaning coils. All other operations should be performed by trained service personnel.

When handling the equipment, observe precautions in the manual and on tags, stickers, and labels attached to the equipment. Follow all safety codes. Wear safety glasses and work gloves. Keep quenching cloth and fire extinguisher nearby when brazing.

Read the instructions thoroughly and follow all warnings or cautions in literature and attached to the unit. Consult local building codes and current editions of national as well as local electrical codes.

Recognize the following safety information:



Warning Incorrect handling could result in personal injury or death.



Caution Incorrect handling may result in minor injury, or damage to product or property.

- Make sure the outdoor unit is installed on a stable, level surface with no accumulation of snow, leaves, or trash beside.
- Make sure the ceiling/wall is strong enough to bear the weight of the unit.
- Make sure the noise of the outdoor unit does not disturb neighbors.
- Follow all the installation instructions to minimize the risk of damage from earthquakes, typhoons or strong winds.
- Avoid contact between refrigerant and fire as it generates poisonous gas.
- Apply specified refrigerant only. Never have it mixed with any other refrigerant. Never have air remain in the refrigerant line as it may lead to rupture and other hazards.
- Make sure no refrigerant gas is leaking out when installation is completed.
- Should there be refrigerant leakage, the density of refrigerant in the air shall in no way exceed its limited value, or it may lead to explosion.
- Keep your fingers and clothing away from any moving parts.
- Clear the site after installation. Make sure no foreign objects are left in the unit.
- Always ensure effective grounding for the unit.



Warning

All electric work must be performed by a licensed technician according to local regulations and the instructions given in this manual.

- Before installing, modifying, or servicing system, main electrical disconnect switch must be in the OFF position. There may be more than 1 disconnect switch. Lock out and tag switch with a suitable warning label.
- Never supply power to the unit unless all wiring and tubing are completed, reconnected and checked.
- This system adopts highly dangerous electrical voltage. Incorrect connection or inadequate grounding can cause personal injury or death. Stick to the wiring diagram and all the instructions when wiring.
- Have the unit adequately grounded in accordance with local electrical codes.
- Have all wiring connected tightly. Loose connection may lead to overheating and a possible fire hazard.

All installation or repair work shall be performed by your dealer or a specialized subcontractor as there is the risk of fire, electric shock, explosion or injury.



Caution

- Never install the unit in a place where a combustible gas might leak, or it may lead to fire or explosion.
- Make a proper provision against noise when the unit is installed at a telecommunication center or hospital.
- Provide an electric leak breaker when it is installed in a watery place.
- Never wash the unit with water.
- Handle unit transportation with care. The unit should not be carried by only one person if it is more than 20kg.
- Never touch the heat exchanger fins with bare hands.
- Never touch the compressor or refrigerant piping without wearing glove.
- Do not have the unit operate without air filter.
- Should any emergency occur, stop the unit and disconnect the power immediately.
- Properly insulate any tubing running inside the room to prevent the water from damaging the wall.

2. Specifications

2.1 Unit Specifications

Model			GWH09RB-K3DNA2C, GWH09RB-K3DNA3C GWH09RB-K3DNA5C, GWH09RB-K3DNA6C GWH09RB-K3DNA8C	
Product Code			CB301001100, CB302000900 CB304000500, CB305000100 CB313000100	
Power Supply	Rated Voltage	V~	220-240	
	Rated Frequency	Hz	50	
	Phases		1	
Power Supply Mode			Indoor	
Cooling Capacity (Min~Max)		W	2600(880~3000)	
Heating Capacity (Min~Max)		W	2750(760~3500)	
Cooling Power Input (Min~Max)		W	720(110~1200)	
Heating Power Input (Min~Max)		W	720(110~1470)	
Cooling Power Current		A	3.13	
Heating Power Current		A	3.13	
Rated Input		W	1550	
Rated Current		A	7.00	
Air Flow Volume(SH/H/M/L/SL)		m ³ /h	650/500/400/300/-	
Dehumidifying Volume		L/h	0.80	
EER		W/W	-	
COP		W/W	-	
SEER		W/W	6.40	
SCOP		W/W	4.00	
Application Area		m ²	12-18	
Indoor Unit	Model of Indoor Unit		GWH09RB-K3DNA2C/I, GWH09RB-K3DNA3C/I GWH09RB-K3DNA5C/I, GWH09RB-K3DNA6C/I GWH09RB-K3DNA8C/I	
	Product Code of Indoor Unit		CB301N01100, CB302N00900 CB304N00500, CB305N00100 CB313N00100	
	Fan Type		Cross-flow	
	Diameter Length(DXL)		mm	Φ92X645
	Fan Motor Cooling Speed (SH/H/M/L/SL)		r/min	1260/1050/900/690/-
	Fan Motor Heating Speed (SH/H/M/L/SL)		r/min	1320/1200/1000/910/-
	Output of Fan Motor		W	20
	Fan Motor RLA		A	0.10
	Fan Motor Capacitor		μF	1.0
	Input of Heater		W	-
	Evaporator Form			Aluminum Fin-copper Tube
	Pipe Diameter		mm	Φ7
	Row-fin Gap		mm	2-1.4
	Coil Length (LXDXW)		mm	640X24.8X266.7
	Swing Motor Model			MP24AA
	Output of Swing Motor		W	2
	Fuse		A	3.15
	Sound Pressure Level (SH/H/M/L/SL)		dB (A)	41/39/36/33/-
	Sound Power Level (SH/H/M/L/SL)		dB (A)	53/49/44/38/-
	Dimension (WXHXD)		mm	845X275X189
	Dimension of Carton Box (LXWXH)		mm	923X264X356
	Dimension of Package (LXWXH)		mm	926X267X371
	Net Weight		kg	10.0
Gross Weight		kg	12.0	

Outdoor Unit	Model of Outdoor Unit		GWH09RB-K3DNA3C/O
	Product Code of Outdoor Unit		CB302W00900
	Compressor Manufacturer/Trademark		ZHUHAI LANDA COMPRESSOR CO., LTD.
	Compressor Model		QXA-A086zE190A
	Compressor Oil		FVC 68D / RB 68EP
	Compressor Type		Rotary
	L.R.A.	A	20.00
	Compressor RLA	A	4.20
	Compressor Power Input	W	881
	Overload Protector		1NT11L-6233
	Throttling Method		Electron expansion valve
	Operation temp	°C	16~30
	Ambient temp (Cooling)	°C	18~43
	Ambient temp (Heating)	°C	-7~24
	Condenser Form		Aluminum Fin-copper Tube
	Pipe Diameter	mm	Φ7
	Rows-fin Gap	mm	2-1.4
	Coil Length (LXD _{XW})	mm	680X38X506
	Fan Motor Speed	rpm	900/650
	Output of Fan Motor	W	30
	Fan Motor RLA	A	0.15
	Fan Motor Capacitor	μF	-
	Air Flow Volume of Outdoor Unit	m ³ /h	2000
	Fan Type		Axial-flow
	Fan Diameter	mm	Φ400
	Defrosting Method		Automatic Defrosting
	Climate Type		T1
	Isolation		I
	Moisture Protection		IP24
	Permissible Excessive Operating Pressure for the Discharge Side	MPa	4.3
	Permissible Excessive Operating Pressure for the Suction Side	MPa	2.5
	Sound Pressure Level (H/M/L)	dB (A)	55/-/-
Sound Power Level (H/M/L)	dB (A)	60/-/-	
Dimension (WXHXD)	mm	776X540X320	
Dimension of Carton Box (LXWXH)	mm	848X360X580	
Dimension of Package (LXWXH)	mm	851X363X595	
Net Weight	kg	30.0	
Gross Weight	kg	32.0	
Refrigerant		R410A	
Refrigerant Charge	kg	0.90	
Connection Pipe	Length	m	5
	Gas Additional Charge	g/m	20
	Outer Diameter Liquid Pipe	mm	Φ6
	Outer Diameter Gas Pipe	mm	Φ9.52
	Max Distance Height	m	10
	Max Distance Length	m	15

The above data is subject to change without notice. Please refer to the nameplate of the unit.

Model			GWH09RB-K3DNA2C, GWH09RB-K3DNA3C	
Product Code			CB301001102, CB302000901	
Power Supply	Rated Voltage	V~	220-240	
	Rated Frequency	Hz	50	
	Phases		1	
Power Supply Mode			Indoor	
Cooling Capacity (Min~Max)		W	2600(880~3000)	
Heating Capacity (Min~Max)		W	2750(760~3500)	
Cooling Power Input (Min~Max)		W	720(110~1200)	
Heating Power Input (Min~Max)		W	720(110~1470)	
Cooling Power Current		A	3.13	
Heating Power Current		A	3.13	
Rated Input		W	1550	
Rated Current		A	7.00	
Air Flow Volume(SH/H/M/L/SL)		m ³ /h	650/500/400/300/-	
Dehumidifying Volume		L/h	0.80	
EER		W/W	-	
COP		W/W	-	
SEER		W/W	6.40	
SCOP		W/W	4.00	
Application Area		m ²	12-18	
Indoor Unit	Model of Indoor Unit		GWH09RB-K3DNA2C/I, GWH09RB-K3DNA3C/I	
	Product Code of Indoor Unit		CB301001102, CB302000901	
	Fan Type		Cross-flow	
	Diameter Length(DXL)		mm	Φ92X645
	Fan Motor Cooling Speed (SH/H/M/L/SL)		r/min	1260/1050/900/690/-
	Fan Motor Heating Speed (SH/H/M/L/SL)		r/min	1320/1200/1000/910/-
	Output of Fan Motor		W	20
	Fan Motor RLA		A	0.10
	Fan Motor Capacitor		μF	1.0
	Input of Heater		W	-
	Evaporator Form			Aluminum Fin-copper Tube
	Pipe Diameter		mm	Φ7
	Row-fin Gap		mm	2-1.4
	Coil Length (LXDXW)		mm	640X24.8X266.7
	Swing Motor Model			MP24AA
	Output of Swing Motor		W	2
	Fuse		A	3.15
	Sound Pressure Level (SH/H/M/L/SL)		dB (A)	41/39/36/33/-
	Sound Power Level (SH/H/M/L/SL)		dB (A)	53/49/44/38/-
	Dimension (WXHXD)		mm	845X275X189
Dimension of Carton Box (LXWXH)		mm	923X264X356	
Dimension of Package (LXWXH)		mm	926X267X371	
Net Weight		kg	10.0	
Gross Weight		kg	12.0	

Outdoor Unit	Model of Outdoor Unit		GWH09RB-K3DNA3C/O	
	Product Code of Outdoor Unit		CB302W00901	
	Compressor Manufacturer/Trademark		ZHUHAI LANDA COMPRESSOR CO., LTD.	
	Compressor Model		QXA-A086zE190A	
	Compressor Oil		FVC 68D / RB 68EP	
	Compressor Type		Rotary	
	L.R.A.	A		20.00
	Compressor RLA	A		4.20
	Compressor Power Input	W		881
	Overload Protector			1NT11L-6233
	Throttling Method			Electron expansion valve
	Operation temp	°C		16~30
	Ambient temp (Cooling)	°C		18~43
	Ambient temp (Heating)	°C		-7~24
	Condenser Form			Aluminum Fin-copper Tube
	Pipe Diameter	mm		Φ7
	Rows-fin Gap	mm		2-1.4
	Coil Length (LXD _X W)	mm		680X38X506
	Fan Motor Speed	rpm		900/650
	Output of Fan Motor	W		30
	Fan Motor RLA	A		0.15
	Fan Motor Capacitor	μF		-
	Air Flow Volume of Outdoor Unit	m ³ /h		2000
	Fan Type			Axial-flow
	Fan Diameter	mm		Φ400
	Defrosting Method			Automatic Defrosting
	Climate Type			T1
	Isolation			I
	Moisture Protection			IP24
	Permissible Excessive Operating Pressure for the Discharge Side	MPa		4.3
	Permissible Excessive Operating Pressure for the Suction Side	MPa		2.5
	Sound Pressure Level (H/M/L)	dB (A)		55/-/-
	Sound Power Level (H/M/L)	dB (A)		60/-/-
Dimension (WXHXD)	mm		776X540X320	
Dimension of Carton Box (LXWXH)	mm		848X360X580	
Dimension of Package (LXWXH)	mm		851X363X595	
Net Weight	kg		30.0	
Gross Weight	kg		32.0	
Refrigerant			R410A	
Refrigerant Charge	kg		0.90	
Connection Pipe	Length	m	5	
	Gas Additional Charge	g/m	20	
	Outer Diameter Liquid Pipe	mm	Φ6	
	Outer Diameter Gas Pipe	mm	Φ9.52	
	Max Distance Height	m	10	
	Max Distance Length	m	15	

The above data is subject to change without notice. Please refer to the nameplate of the unit.

Model			GWH12RB-K3DNA2C, GWH12RB-K3DNA3C GWH12RB-K3DNA5C, GWH12RB-K3DNA6C GWH12RB-K3DNA8C	
Product Code			CB301001200, CB302001000 CB304000600, CB305000200 CB313000200	
Power Supply	Rated Voltage	V~	220-240	
	Rated Frequency	Hz	50	
	Phases		1	
Power Supply Mode			Indoor	
Cooling Capacity (Min~Max)		W	3500(480~4000)	
Heating Capacity (Min~Max)		W	3650(650~4280)	
Cooling Power Input (Min~Max)		W	1100(110~1300)	
Heating Power Input (Min~Max)		W	1100(110~1580)	
Cooling Power Current		A	4.78	
Heating Power Current		A	4.78	
Rated Input		W	1700	
Rated Current		A	8.00	
Air Flow Volume(SH/H/M/L/SL)		m ³ /h	650/500/400/300/-	
Dehumidifying Volume		L/h	1.20	
EER		W/W	-	
COP		W/W	-	
SEER		W/W	6.40	
SCOP		W/W	3.80	
Application Area		m ²	16-24	
Indoor Unit	Model of Indoor Unit		GWH12RB-K3DNA2C/I, GWH12RB-K3DNA3C/I GWH12RB-K3DNA5C/I, GWH12RB-K3DNA6C/I GWH12RB-K3DNA8C/I	
	Product Code of Indoor Unit		CB301N01200, CB302N01000 CB304N00600, CB305N00200 CB313N00200	
	Fan Type		Cross-flow	
	Diameter Length(DXL)		mm	Φ92X645
	Fan Motor Cooling Speed (SH/H/M/L/SL)		r/min	1290/1070/900/690/-
	Fan Motor Heating Speed (SH/H/M/L/SL)		r/min	1280/1050/980/920/-
	Output of Fan Motor		W	20
	Fan Motor RLA		A	0.10
	Fan Motor Capacitor		μF	1.0
	Input of Heater		W	-
	Evaporator Form			Aluminum Fin-copper Tube
	Pipe Diameter		mm	Φ7
	Row-fin Gap		mm	2-1.4
	Coil Length (LXDXW)		mm	640X24.8X266.7
	Swing Motor Model			MP24AA
	Output of Swing Motor		W	2
	Fuse		A	3.15
	Sound Pressure Level (SH/H/M/L/SL)		dB (A)	45/42/39/36/-
	Sound Power Level (SH/H/M/L/SL)		dB (A)	55/52/49/46/-
	Dimension (WXHXD)		mm	845X275X189
	Dimension of Carton Box (LXWXH)		mm	923X264X356
	Dimension of Package (LXWXH)		mm	926X267X371
	Net Weight		kg	10.0
Gross Weight		kg	12.0	

Outdoor Unit	Model of Outdoor Unit		GWH12RB-K3DNA3C/O
	Product Code of Outdoor Unit		CB302W01000
	Compressor Manufacturer/Trademark		ZHUHAI LANDA COMPRESSOR CO., LTD.
	Compressor Model		QXA-A091zE190A
	Compressor Oil		FVC 68D / RB 68EP
	Compressor Type		Rotary
	L.R.A.	A	20.00
	Compressor RLA	A	4.50
	Compressor Power Input	W	942
	Overload Protector		1NT11L-6233
	Throttling Method		Electron expansion valve
	Operation temp	°C	16~30
	Ambient temp (Cooling)	°C	18~43
	Ambient temp (Heating)	°C	-7~24
	Condenser Form		Aluminum Fin-copper Tube
	Pipe Diameter	mm	Φ9.52
	Rows-fin Gap	mm	2-1.4
	Coil Length (LXDXW)	mm	730X38.1X508
	Fan Motor Speed	rpm	900/650
	Output of Fan Motor	W	30
	Fan Motor RLA	A	0.15
	Fan Motor Capacitor	μF	-
	Air Flow Volume of Outdoor Unit	m ³ /h	2000
	Fan Type		Axial-flow
	Fan Diameter	mm	Φ400
	Defrosting Method		Automatic Defrosting
	Climate Type		T1
	Isolation		I
	Moisture Protection		IP24
	Permissible Excessive Operating Pressure for the Discharge Side	MPa	4.3
	Permissible Excessive Operating Pressure for the Suction Side	MPa	2.5
	Sound Pressure Level (H/M/L)	dB (A)	58/-/-
	Sound Power Level (H/M/L)	dB (A)	63/-/-
Dimension (WXHXD)	mm	848X540X320	
Dimension of Carton Box (LXWXH)	mm	878X360X580	
Dimension of Package (LXWXH)	mm	881X363X595	
Net Weight	kg	33.0	
Gross Weight	kg	35.0	
Refrigerant		R410A	
Refrigerant Charge	kg	1.15	
Connection Pipe	Length	m	5
	Gas Additional Charge	g/m	20
	Outer Diameter Liquid Pipe	mm	Φ6
	Outer Diameter Gas Pipe	mm	Φ9.52
	Max Distance Height	m	10
	Max Distance Length	m	20

The above data is subject to change without notice. Please refer to the nameplate of the unit.


Model			GWH12RB-K3DNA2C, GWH12RB-K3DNA3C	
Product Code			CB301001202, CB302001001	
Power Supply	Rated Voltage	V~	220-240	
	Rated Frequency	Hz	50	
	Phases		1	
Power Supply Mode			Indoor	
Cooling Capacity (Min~Max)		W	3500(480~4000)	
Heating Capacity (Min~Max)		W	3650(650~4280)	
Cooling Power Input (Min~Max)		W	1100(110~1300)	
Heating Power Input (Min~Max)		W	1100(110~1580)	
Cooling Power Current		A	4.78	
Heating Power Current		A	4.78	
Rated Input		W	1700	
Rated Current		A	8.00	
Air Flow Volume(SH/H/M/L/SL)		m ³ /h	650/500/400/300/-	
Dehumidifying Volume		L/h	1.20	
EER		W/W	-	
COP		W/W	-	
SEER		W/W	6.40	
SCOP		W/W	3.80	
Application Area		m ²	16-24	
Indoor Unit	Model of Indoor Unit		GWH12RB-K3DNA2C/I, GWH12RB-K3DNA3C/I	
	Product Code of Indoor Unit		CB301N01201, CB302N01001	
	Fan Type		Cross-flow	
	Diameter Length(DXL)		mm	Φ92X645
	Fan Motor Cooling Speed (SH/H/M/L/SL)		r/min	1290/1070/900/690/-
	Fan Motor Heating Speed (SH/H/M/L/SL)		r/min	1280/1050/980/920/-
	Output of Fan Motor		W	20
	Fan Motor RLA		A	0.10
	Fan Motor Capacitor		μF	1.0
	Input of Heater		W	-
	Evaporator Form			Aluminum Fin-copper Tube
	Pipe Diameter		mm	Φ7
	Row-fin Gap		mm	2-1.4
	Coil Length (LXDXW)		mm	640X24.8X266.7
	Swing Motor Model			MP24AA
	Output of Swing Motor		W	2
	Fuse		A	3.15
	Sound Pressure Level (SH/H/M/L/SL)		dB (A)	45/42/39/36/-
	Sound Power Level (SH/H/M/L/SL)		dB (A)	55/52/49/46/-
	Dimension (WXHXD)		mm	845X275X189
Dimension of Carton Box (LXWXH)		mm	923X264X356	
Dimension of Package (LXWXH)		mm	926X267X371	
Net Weight		kg	10.0	
Gross Weight		kg	12.0	

Outdoor Unit	Model of Outdoor Unit		GWH12RB-K3DNA3C/O
	Product Code of Outdoor Unit		CB302W01001
	Compressor Manufacturer/Trademark		ZHUHAI LANDA COMPRESSOR CO., LTD.
	Compressor Model		QXA-A091zE190A
	Compressor Oil		FVC 68D / RB 68EP
	Compressor Type		Rotary
	L.R.A.	A	20.00
	Compressor RLA	A	4.50
	Compressor Power Input	W	942
	Overload Protector		1NT11L-6233
	Throttling Method		Electron expansion valve
	Operation temp	°C	16~30
	Ambient temp (Cooling)	°C	18~43
	Ambient temp (Heating)	°C	-7~24
	Condenser Form		Aluminum Fin-copper Tube
	Pipe Diameter	mm	Φ9.52
	Rows-fin Gap	mm	2-1.4
	Coil Length (LXDXW)	mm	730X38.1X508
	Fan Motor Speed	rpm	900/650
	Output of Fan Motor	W	30
	Fan Motor RLA	A	0.15
	Fan Motor Capacitor	μF	-
	Air Flow Volume of Outdoor Unit	m ³ /h	2000
	Fan Type		Axial-flow
	Fan Diameter	mm	Φ400
	Defrosting Method		Automatic Defrosting
	Climate Type		T1
	Isolation		I
	Moisture Protection		IP24
	Permissible Excessive Operating Pressure for the Discharge Side	MPa	4.3
	Permissible Excessive Operating Pressure for the Suction Side	MPa	2.5
	Sound Pressure Level (H/M/L)	dB (A)	58/-/-
	Sound Power Level (H/M/L)	dB (A)	63/-/-
Dimension (WXHXD)	mm	848X540X320	
Dimension of Carton Box (LXWXH)	mm	878X360X580	
Dimension of Package (LXWXH)	mm	881X363X595	
Net Weight	kg	33.0	
Gross Weight	kg	35.0	
Refrigerant		R410A	
Refrigerant Charge	kg	1.15	
Connection Pipe	Length	m	5
	Gas Additional Charge	g/m	20
	Outer Diameter Liquid Pipe	mm	Φ6
	Outer Diameter Gas Pipe	mm	Φ9.52
	Max Distance Height	m	10
	Max Distance Length	m	20


The above data is subject to change without notice. Please refer to the nameplate of the unit.

2.2 Operation Characteristic Curve

Cooling




Heating




2.3 Capacity Variation Ratio According to Temperature

Cooling



Heating



2.4 Operation Data

Cooling

Temperature condition (°C)		Model name	Standard pressure P (MPa)	Heat exchanger pipe temp.		Indoor fan mode	Outdoor fan mode(rpm)	Compressor revolution (Hz)
Indoor	Outdoor			T1 (°C)	T2 (°C)			
27/19	35/24	09K	0.85~1.0	in:8~11	in:50~80	Turbo	900	54
		12K		out:11~14	out:37~43	Turbo		75

Heating

Temperature condition (°C)		Model name	Standard pressure P (MPa)	Heat exchanger pipe temp.		Indoor fan mode	Outdoor fan mode(rpm)	Compressor revolution (Hz)
Indoor	Outdoor			T1 (°C)	T2 (°C)			
20/-	7/6	09K	2.5~3.0	in:50~80	in:1~3	Turbo	900	60
		12K		out:37~43	out:2~5	Turbo		80

T1: Inlet and outlet pipe temperature of evaporator

T2: Inlet and outlet pipe temperature of condenser

P: Pressure of air pipe connecting indoor and outdoor units



NOTES :

(1) Measure surface temperature of heat exchanger pipe around center of heat exchanger path U bent. (Thermistor thermometer)

(2) Connecting piping condition : 5 m


2.5 Noise Criteria Curve Tables for Both Models

Indoor side noise when blowing




3. Construction Views

3.1 Indoor Unit




3.2 Outdoor Unit

GWH09RB-K3DNA3C/O(CB302W00900)




Unit: mm


GWH09RB-K3DNA3C/O(CB302W00901)




GWH12RB-K3DNA3C/O(CB302W01000)



GWH12RB-K3DNA3C/O(CB302W01001)



4. Refrigerant System Diagram



Refrigerant pipe diameter

Liquid : 1/4" (6 mm)

Gas : 3/8" (9.52 mm)

5. Schematic Diagram


5.1 Electrical Wiring

- Electrical Data


Symbol	Color symbol	Symbol	Parts name
BU	BLUE	COMP	COMPRESSOR
YE	YELLOW	CT12	OVERLOAD
RD	RED	4V	4-WAY VALVE
OG	ORANGE	⊕	PROTECTIVE EARTH
BN	BROWN	EKV	ELECTRONIC EXPANSION VALVE
BK	BLACK		
YEGN	YELLOW GREEN		
WH	WHITE		

- Indoor Unit


GWH09RB-K3DNA2C/I(CB301N01100), GWH09RB-K3DNA2C/I(CB301N01101), GWH09RB-K3DNA3C/I(CB302N00900)
 GWH09RB-K3DNA5C/I(CB304N00500), GWH09RB-K3DNA8C/I(CB313N00100), GWH12RB-K3DNA2C/I(CB301N01200)
 GWH12RB-K3DNA2C/I(CB301N01201), GWH12RB-K3DNA3C/I(CB302N01000), GWH12RB-K3DNA5C/I(CB304N00600)
 GWH12RB-K3DNA8C/I(CB313N00200), GWH09RB-K3DNA6C/I(CB305N00100), GWH12RB-K3DNA6C/I(CB305N00200)



GWH09RB-K3DNA3C/I(CB302N00901), GWH12RB-K3DNA3C/I(CB302N01001)



● Outdoor Unit




These circuit diagrams are subject to change without notice, please refer to the one supplied with the unit.


5.2 Printed Circuit Board

(1) Indoor unit

● TOP VIEW




● BOTTOM VIEW




6. Function and Control

6.1 Remote Control Operations



- 1 **ON/OFF**
Press it to start or stop operation.
- 2 **-**
Press it to decrease temperaturesetting.
- 3 **+**
Press it to increase temperaturesetting.
- 4 **MODE**
Press it to select operation mode(AUTO/COOL/DRY/FAN/HEAT).
- 5 **FAN**
Press it to set fan speed.
- 6 **SWING**
Press it to set swing angle.
- 7 **I FEEL**
- 8 **HEALTH/AIR**
Press it to set HEALTH or AIR function.
- 9 **SLEEP**
- 10 **TEMP**
- 11 **TIMER ON**
Press it to set auto-on timer.
- 12 **CLOCK**
Press it to set clock function.
- 13 **TIMER OFF**
Press it to set auto-off timer.
- 14 **TURBO**
- 15 **LIGHT**
Press it to turn on/off the light.
- 16 **X-FAN**



- 17 **MODE icon:**
If MODE button is pressed,current operation mode icon (AUTO), (COOL), (DRY), (FAN) or (HEAT only for heat pumpmodels) will show.
- 18 **SLEEP icon :**
 is displayed by pressing the SLEEP button. Press this button again to clear the display.
- 19 **LIGHT icon:**
 is displayed by pressing the LIGHT button. Press LIGHT button again to clear the display.
- 20 **TEMP icon:**
Pressing TEMP button, (set temperature), (indoor ambient temperature) , (outdoor ambient temperature) and blank is displayed circularly.
- 21 **Up & down swing icon:**
 is displayed when pressing the up & down swing down button. Press this button again to clear the display.

22 LOCK icon:

🔒 is displayed by pressing "+" and "-" buttons simultaneously. Press them again to clear the display.

23 SET TIME display:


After pressing TIMER button, ON or OFF will blink. This area will show the set time.

24 DIGITAL display:

This area will show the set temperature. In SAVE mode, "SE" will be displayed.

25 AIR icon:

🏠 is displayed when pressing the AIR button. Press this button again to clear the display.



26 HEALTH icon:

👤 is displayed when pressing the HEALTH button. Press this button again to clear the display.

27 X-FAN icon:

🌀 is displayed when pressing the X-FAN button. Press this button again to clear the display.

28 TURBO icon:

⚡ is displayed when pressing the TURBO button. Press this button again to clear the display.

29 FAN SPEED display:

Press FAN button to select the desired fan speed setting (AUTO, Low, Med, High). Your selection will be displayed in the LCD windows, except the AUTO fan speed.

30 I FEEL icon:

☀️ is displayed when pressing the I FEEL button. Press this button again to clear the display.

31 Heating icon:

💰 is displayed when Pressing "TEMP" and "CLOCK" simultaneously in Heat mode.

Remote Controller Description

1 ON/OFF :

Press this button to turn on the unit. Press this button again to turn off the unit.

2 - :

Press this button to decrease set temperature. Hold it down for above 2 seconds to rapidly decrease set temperature. In AUTO mode, set temperature is not adjustable.

3 + :

Press this button to increase set temperature. Hold it down for above 2 seconds to rapidly increase set temperature. In AUTO mode, set temperature is not adjustable.

4 MODE :

Each time you press this button, a mode is selected in a sequence that goes from AUTO, COOL, DRY, FAN, and HEAT *, as the following:



*Note: Only for models with heating function.

After energization, AUTO mode is defaulted. In AUTO mode, the set temperature will not be displayed on the LCD, and the unit will automatically select the suitable operation mode in accordance with the room temperature to make indoor room comfortable.

5 FAN :

This button is used for setting Fan Speed in the sequence that goes from AUTO, 📶, 📶, 📶 to 📶 then back to Auto.



6 SWING:

Press this button to set up & down swing angle, which circularly changes as below:







This remote controller is universal. If any command  ,  or  is sent out, the unit will carry out the command as 

 indicates the guide louver swings as: 

7 I FEEL:

Press this button to turn on I FEEL function. The unit automatically adjust temperature according to the sensed temperature. Press this button again to cancel I FEEL function.


8 

Press this button to achieve the on and off of healthy and scavenging functions in operation status. Press this button for the first time to start scavenging function; LCD displays "  ". Press the button for the second time to start healthy and scavenging functions simultaneously; LCD displays "  " and "  ". Press this button for the third time to quit healthy and scavenging functions simultaneously. Press the button for the fourth time to start healthy function; LCD display "  ". Press this button again to repeat the operation above.

9 SLEEP:


Press this button to go into the SLEEP operation mode. Press it again to cancel this function. This function is available in COOL , HEAT (Only for models with heating function) or DRY mode to maintain the most comfortable temperature for you.

10 TEMP:



Press this button, could select displaying the indoor setting temperature or indoor ambient temperature. When the indoor unit firstly power on it will display the setting temperature, if the temperature's displaying status is changed from other status to "  ", displays the ambient temperature, 3s later or within 3s, it receives other remote control signal that will return to display the setting temperature. if the users haven't set up the temperature displaying status, that will display the setting temperature.

11 TIMER ON :

Press this button to initiate the auto-ON timer. To cancel the auto-timer program, simply press this button again.

After press of this button,  disappear sand " ON " blinks .00:00 is displayed for ON time setting. Within 5 seconds, press + or - button to adjust the time value. Every press of either button changes the time setting by 1 minute. Hold down either button to rapidly change the time setting by 1 minute and then 10 minutes. Within 5 seconds after setting, press TIMER ON button to confirm.

12 CLOCK :

Press CLOCK button,  blinking. Within 5 seconds, pressing + or - button adjusts the present time. Hold down either button for above 2 seconds to increase or decrease the time by 1 minute every 0.5 second and then by 10 minutes every 0.5 second. During blinking after setting, press CLOCK button again to confirm the setting, and then  will be constantly displayed.



13 TIMER OFF :

Press this button to initiate the auto-off timer. To cancel the auto-timer program, simply press the button again. TIMER OFF setting is the same as TIMER ON.

14 TURBO:

Press this button to activate / deactivate the Turbo function which enables the unit to reach the preset temperature in the shortest time. In COOL mode, the unit will blow strong cooling air at super high fan speed. In HEAT mode, the unit will blow strong heating air at super high fan speed.

15 LIGHT:



Press LIGHT button to turn on the display's light and press this button again to turn off the display 's light. If the light is turned on ,  is displayed. If the light is turned off,  disappears.

16 X-FAN:

Pressing X-FAN button in COOL or DRY mode, the icon  is displayed and the indoor fan will continue operation for 2 minutes in order to dry the indoor unit even though you have turned off the unit.

After energization, X-FAN OFF is defaulted. X-FAN is not available in AUTO, FAN or HEAT mode.

17 Combination of "+" and "-" buttons: About lock

Press "+" and "-" buttons simultaneously to lock or unlock the keypad. If the remote controller is locked,  is displayed. In this case, pressing any button,  blinks three times.

18 Combination of "MODE " and "-" buttons : About switch between Fahrenheit and centigrade At unit OFF, press "MODE" and "-"

buttons simultaneously to switch between  and .

19 Combination of " TEMP " and "CLOCK" buttons : About Energy-saving Function

Press "TEMP" and "CLOCK" simultaneously in COOL mode to start energy-saving function. Nixie tube on the remote controller displays "SE". Repeat the operation to quit the function.

20 Combination of " TEMP " and "CLOCK" buttons : About 8 Heating Function

Press “TEMP” and “CLOCK” simultaneously in HEAT mode to start 8 Heating Function Nixie tube on the remote controller displays “ 8 ” and a selected temperature of “ 8 ”. (46 if Fahrenheit is adopted). Repeat the operation to quit the function.

21 About Back-lighting Function


The unit lights for 4s when energizing for the first time, and 3s for later press.

Replacement of Batteries

- 1.Remove the battery cover plate from the rear of the remote controller.
(As shown in the figure)
- 2.Take out the old batteries.
- 3.Insert two new AAA1.5V dry batteries, and pay attention to the polarity.
4. Reinstall the battery cover plate.

Notes:

- When replacing the batteries, do not use old or different types of batteries, otherwise, it may cause malfunction.
- If the remote controller will not be used for a long time, please remove batteries to prevent batteries from leaking.
- The operation should be performed in its receiving range.
- It should be kept 1m away from the TV set or stereo sound sets.
- If the remote controller does not operate normally, please take the batteries out and reinsert them after 30 seconds.If it still can't operate properly, replace the batteries.



Sketch map for replacing batteries

6.2 Description of Each Control Operation

1. Temperature Parameters

- ◆ Indoor preset temperature (T_{preset})
- ◆ Indoor ambient temperature ($T_{\text{amb.}}$)

2. Basic Functions

Once energized, in no case should the compressor be restarted within less than 3 minutes. In the situation that memory function is available, for the first energization, if the compressor is at stop before de-energization, the compressor will be started without a 3-minute lag; if the compressor is in operation before de-energization, the compressor will be started with a 3-minute lag; and once started, the compressor will not be stopped within 6 minutes regardless of changes in room temperature;

(1) COOL mode


① The condition and process of cooling

If $T_{\text{amb.}} \geq T_{\text{preset}}$ COOL mode will act, the compressor and outdoor fan will run, and the indoor fan will run at the set speed.

If $T_{\text{amb.}} \leq T_{\text{preset}} - 2^\circ\text{C}$, the compressor will stop, the outdoor fan will delay 30 seconds to stop, and the indoor fan will run at the set speed.

If $T_{\text{preset}} - 2^\circ\text{C} \leq T_{\text{amb.}} \leq T_{\text{preset}}$, the unit will keep running in the previous mode.

In this mode, the reversal valve will not be powered on and the temperature setting range is $16^\circ\text{C} \sim 30^\circ\text{C}$.




② Protection function

◆ Overcurrent protection

If total current is high, the compressor will run in limited frequency. If total current is too high, the compressor will stop, the outdoor fan will delay 30 seconds to stop, indoor unit will display E5 and outdoor yellow light will blink 5 times.

◆ Antifreezing protection

When the antifreezing protection is detected, the compressor will stop, the outdoor fan will stop after 30 seconds, and the indoor fan and swing motor will keep running in the original mode. When antifreezing protection is eliminated and the compressor has stopped for 3 minutes, the compressor will resume running in the original mode.



(2) Dehumidifying Mode

① Working conditions and process of dehumidifying

If $T_{\text{amb.}} > T_{\text{preset}}$, the unit will enter cooling and dehumidifying mode, in which case the compressor and the outdoor fan will operate and the indoor fan will run at low speed.

If $T_{\text{preset}} - 2^\circ\text{C} \leq T_{\text{amb.}} \leq T_{\text{preset}}$, the compressor remains at its original operation state.

If $T_{\text{amb.}} < T_{\text{preset}} - 2^\circ\text{C}$, the compressor will stop, the outdoor fan will stop with a time lag of 30s, and the indoor fan will operate at low speed.

② Protection

Protection is the same as that under the cooling mode.

(3) HEAT mode


① The condition and process of heating

If $T_{amb} \leq T_{preset} + 2^\circ C$, HEAT mode will act, the compressor, outdoor fan and reversal valve will run, the indoor fan will delay 3min to stop at the latest

If $T_{preset} + 2^\circ C < T_{amb} < T_{preset} + 5^\circ C$, the unit will keep running in the original mode.


If $T_{amb} \geq T_{preset} + 5^\circ C$, the compressor will stop, the outdoor fan will delay 30sec to stop and indoor fan will blow 60S at low speed, the fan speed cannot be shifted within blow residual heat.

- In this mode, the temperature setting range is $16^\circ C \sim 30^\circ C$.
- The air conditioner will adjust the running frequency of the compressor automatically according to the change of ambient temperature.
- When the unit is turned off in HEAT mode, or switched to other mode from HEAT mode, the four-way valve will be powered off after the compressor stops.
- When compressor is running (not including each malfunction and protection):
 - a. When outdoor ambient temperature ≥ 20 and indoor fan speed is low or medium, the fan speed will turn to high; if indoor fan speed is high or super high, it will keep the same.
 - b. When outdoor ambient temperature ≤ 18 , the fan speed will resume set fan speed.
 - c. When $18 < \text{outdoor ambient temperature} < 20$, it will run at present fan speed (set fan speed or high fan speed); but when first exiting cold air prevention after entering heating mode, it will run in set fan speed.



② The condition and process of defrosting

When frost is detected in the condenser, the system will enter into defrosting state. When defrosting starts, the compressor and indoor fan will stop, and the outdoor fan and four-way valve will delay 30 seconds to stop. The compressor will start after 15 seconds and then defrosting will be started. When the compressor has run for 7 minutes or defrosting is finished, the compressor will stop. After 30 seconds the four-way valve opens and after another 60 seconds, the compressor and outdoor fan resume running. The indoor fan will delay 3 minutes to run at the latest and temperature on the display panel shows H1.



③ Protection function

Anti-cold-wind protection

In HEAT mode, in order to prevent the indoor unit from blowing out cold wind, each time the compressor starts, the indoor fan will delay 3 minutes after the compressor to run at the latest and it can adjust fan speed automatically when temperature is low.

Overcurrent protection

Overcurrent protection is the same with that in COOL_{mode}.

3. Protection

◆ Cold air prevention

The unit is started under heating mode (the compressor is ON):

- ① In the case of $T_{indoor\ amb.} < 24^\circ C$: if $T_{tube} \leq 40^\circ C$ and the indoor fan is at stop state, the indoor fan will begin to run at low speed with a time lag of 2 minutes. Within 2 minutes, if $T_{tube} > 40^\circ C$, the indoor fan also will run at low speed; and after 1-minute operation at low speed, the indoor fan will be converted to operation at preset speed. Within 1-minute low speed operation or 2-minute non-operation, if $T_{tube} > 42^\circ C$, the fan will run at present speed.
- ② In the case of $T_{indoor\ amb.} \geq 24^\circ C$: if $T_{tube} \leq 42^\circ C$, the indoor fan will run at low speed, and after one minute, the indoor fan will be converted to preset speed. Within one-minute low speed operation, if $T_{tube} > 42^\circ C$, the indoor fan will be converted to preset speed.

Note: $T_{\text{indoor amb}}$ indicated in 1 and 2 refers to, under initially heating mode, the indoor ambient temperature before the command to start the compressor is performed according to the program, or after the unit is withdrawn from defrost, the indoor ambient temperature before the defrost symbol is cleared.

◆ Total current up and frequency down protection

If the total current $I_{\text{total}} \leq W$, frequency rise will be allowed; if $I_{\text{total}} \geq X$, frequency rise will not be allowed; if $I_{\text{total}} \geq Y$, the compressor will run at reduced frequency; and if $I_{\text{total}} \geq Z$, the compressor will stop and the outdoor fan will stop with a time lag of 30s.

(4) Fan Mode

Under the mode, the indoor fan will run at preset speed and the compressor, the outdoor fan, the four-way valve and the electric heater will stop.

➤ Under the mode, temperature can be set within a range of 16 - 30°C.

(5) AUTO Mode

1. Operation way of AUTO mode: :

a. When $T_{\text{ambient}} \geq 26$, it will run in cooling mode. The implied set temperature is 25 (note: the set temperature sending to outdoor unit is 25).

b. For heating and cooling unit, when $T_{\text{ambient}} \leq (19 + T_{\text{supplementary}})$, it will run in heating mode. The implied set temperature is 20; for cooling only unit, when $T_{\text{ambient}} \leq 22$, it will run in fan mode and the displayed set temperature is 25.

c. For heating and cooling unit, when $(19 + T_{\text{supplementary}}) < T_{\text{indoor ambient}} < 26$ (for cooling only unit, $22 < T_{\text{indoor ambient}} < 26$), it will keep the original running mode. If the unit is energized for the first time, it will run in fan mode.

2. Protection

a. In cooling operation, protection is the same as that under the cooling mode;

b. In heating operation, protection is the same as that under the heating mode;

c. When ambient temperature changes, operation mode will be converted preferentially. Once started, the compressor will remain unchanged for at least 6 minutes.

(6) Common Protection Functions and Fault Display under COOL, HEAT, DRY and AUTO Modes

① Overload protection

T_{tube} : measured temperature of outdoor heat exchanger under cooling mode; and measured temperature of indoor heat exchanger under heating mode.

1) Cooling overload

a. If $T_{\text{tube}} \leq 52^\circ\text{C}$, the unit will return to its original operation state.

b. If $T_{\text{tube}} \geq 55^\circ\text{C}$, frequency rise is not allowed.

c. If $T_{\text{tube}} \geq 58^\circ\text{C}$, the compressor will run at reduced frequency.

d. If $T_{\text{tube}} \geq 62^\circ\text{C}$, the compressor will stop and the indoor fan will run at preset speed.

2) Heating overload

a. If $T_{\text{tube}} \leq 50^\circ\text{C}$, the unit will return to its original operation state.

b. If $T_{\text{tube}} \geq 53^\circ\text{C}$, frequency rise is not allowed.

c. If $T_{\text{tube}} \geq 56^\circ\text{C}$, the compressor will run at reduced frequency.

d. If $T_{\text{tube}} \geq 60^\circ\text{C}$, the compressor will stop and the indoor fan will blow residue heat and then stop.

② Exhaust temperature protection of compressor

If exhaust temperature $\geq 98^\circ\text{C}$, frequency is not allowed to rise.

If exhaust temperature $\geq 103^\circ\text{C}$, the compressor will run at reduced frequency.

If exhaust temperature $\geq 110^\circ\text{C}$, the compressor will stop.

If exhaust temperature $\leq 90^\circ\text{C}$ and the compressor has stayed at stop for at least 3 minutes, the compressor will resume its operation.

③ Communication fault

If the unit fails to receive correct signals for durative 3 minutes, communication fault can be justified and the whole system will stop.

④ Module protection

Under module protection mode, the compressor will stop. When the compressor remains at stop for at least 3 minutes, the compressor will resume its operation. If module protection occurs six times in succession, the compressor will not be started again.

⑤ Overload protection

If temperature sensed by the overload sensor is over 115°C , the compressor will stop and the outdoor fan will stop with a time lag of 30 seconds. If temperature is below 95°C , the overload protection will be relieved.

⑥ If voltage on the DC bus is below 150V or over 420V, the compressor will stop and the outdoor fan will stop with a time lag of 30 seconds. When voltage on the DC bus returns to its normal value and the compressor has stayed at stop for at least 3 minutes, the compressor will resume its operation.

⑦ Faults of temperature sensors

Designation of sensors	Faults
Indoor ambient temperature	The sensor is detected to be open-circuited or short-circuited for successive 5 seconds
Indoor tube temperature	The sensor is detected to be open-circuited or short-circuited for successive 5 seconds
Outdoor ambient temperature	The sensor is detected to be open-circuited or short-circuited for successive 30 seconds
Outdoor tube temperature	The sensor is detected to be open-circuited or short-circuited for successive 30 seconds, and no detection is performed within 10 minutes after defrost begins.
Exhaust	After the compressor has operated for 3 minutes, the sensor is detected to be open-circuited or short-circuited for successive 30 seconds.
Overload	After the compressor has operated for 3 minutes, the sensor is detected to be open-circuited or short-circuited for successive 30 seconds.

3. Other Controls

(1) ON/OFF

Press the remote button ON/OFF: the on-off state will be changed once each time you press the button.

(2) Mode Selection:

Press the remote button MODE, then select and show in the following ways: AUTO, COOL, DRY, FAN, HEAT, AUTO.

(3) Temperature Setting Option Button

Each time you press the remote button TEMP+ or TEMP-, the setting temperature will be up or down by 1 °C. Regulating Range: 16~30°C, the button is useless under the AUTO mode.

(4) Time Switch

You should start and stop the machine according to the setting time by remote control.

(5) SLEEP State Control

a. When the air conditioner is under the mode of COOL, and the SLEEP mode has been set well, after the SLEEP state keeps about 1 hour, the pre-setting T will raise 1 °C, and it will raise 1 °C again after 2 hours, so it raise 2 °C in 2 hours, then it will run on at the setting temperature and wind speed.

b. When the air conditioner is under the mode of HEAT, and the Timer has been set well, after the SLEEP state keeps about 1 hour, the pre-setting T will reduce 1 °C, and it will reduce 1 °C again after 2 hours, so it reduce 2 °C in 2 hours, then it will run on at the setting temperature and wind speed.

c. The setting temperature keeps the same under the FAN mode and AUTO mode.

(6) Indoor Fan Control

Indoor fan could be set at ultra-high, high, medium, low speed by wireless remote controller and operated as that speed.

Auto fan speed could be set as well, indoor fan will operate under auto fan speed as following:

1. Under heating mode: auto speed under heating or auto heating mode:

a. When $T_{amb} \leq T_{preset} + 1^\circ\text{C}$, indoor fan will operate at high speed;

b. When $T_{preset} + 1^\circ\text{C} < T_{amb} < T_{preset} + 3^\circ\text{C}$, indoor fan will operate at medium speed;

c. When $T_{amb} \geq T_{preset} + 3^\circ\text{C}$, indoor fan will operate at low speed;

There should be at least 180s operation time during switchover of each speed.

2. Under cooling mode: auto speed under cooling or auto cooling mode:

a. When $T_{amb} < T_{preset} + 2^\circ\text{C}$, indoor fan will operate at high speed;

b. When $T_{preset} < T_{amb} < T_{preset} + 2^\circ\text{C}$, indoor fan will operate at medium speed;

c. When $T_{amb} \leq T_{preset}$, indoor fan will operate at low speed

There should be at least 180s operation time during switchover of each speed.

(7) Buzzer Control

The buzzer will send a "Di" sound when the air conditioner is powered up or received the information sent by the remote control or there is a button input, the single tube cooler doesn't receive the remote control ON signal under the mode of heating mode.

(8) Auto button


If the controller is on, it will stop by pressing the button, and if the controller is off, it will be automatic running state by pressing the button, swing on and light on, and the main unit will run based on the remote control if there is remote control order.

(9) Up-and-Down Swinging Control

When power on, the up-and-down motor will firstly move the air deflector to o counter-clockwise, close the air outlet.

After starting the machine, if you don't set the swinging functi on, heating mode and auto-heating mode, the up-and-down air deflector will move to D clockwise; under other modes, the up-and-down air deflector will move to L1. If you set the swinging function when you start the machine, then the wind blade will swing between L and D. The air deflector has 7

swinging states: Location L, Location A, Location B, Location C, Location D, Location L to Location D, stop at any location between L-D (the included angle between L~D is the same). The air deflector will be closed at 0 Location, and the swinging is effectual only on condition that setting the swinging order and the inner fan is running. The indoor fan and compressor may get the power when air deflector is on the default location.



(10) Display

① Operation pattern and mode pattern display

All the display patterns will display for a time when the power on, the operation indication pattern will display in red under standby status. When the machine is start by remote control, the indication pattern will light and display the current operation mode (the mode light includes: Cooling, heating and dehumidify). If you close the light key, all the display patterns will close.

② Double-8 display

According to the different setting of remote control, the nixie light may display the current temperature (the temperature scope is from 16°C to 30°C) and indoor ambient temperature. The heating and air supply temperature will display 25°C under auto-mode, the temperature will display 20°C under the auto-heating mode, and the temperature will display H1 under the defrosting mode.(If you set the fahrenheit temperature display, the nixie light will display according to fahrenheit temperature)

(11) Protection function and failure display

E2: Freeze-proofing protection E4: Exhausting protection E5: Overcurrent protection

E6: Communication failure

F1: Indoor ambient sensor start and short circuit (continuously measured failure in 30S)

F2: Indoor evaporator sensor start and short circuit (continuously measured failure in 30S)

F3: Outdoor ambient sensor start and short circuit (continuously measured failure in 30S)

F4: Outdoor condenser sensor start and short circuit (continuously measured failure in 30S, and don't measure within 10 minutes after defrosted)

F5: Outdoor exhausting sensor start and short circuit (continuously measured failure in 30S after the compressor operated 3 minutes)

H3: Overload protection of compressor H5: Module protection

PH: High-voltage protection PL: Low-voltage protection

P1: Nominal cooling and heating test P2: Maximum cooling and heating test

P3: Medium cooling and heating test P0: Minimum cooling and heating test

(12) Drying Function

You may start or stop the drying function under the modes of cooling and dehumidify at the starting status (The modes of automatism, heating and air supply do not have drying function). When you start the drying function, after stop the machine by pressing the switch button, you should keep running the inner fans for 2 minutes under low air damper (The swing will operate as the former status within 2 minutes, and other load is stopped), then stop the entire machine; When you stop the drying function, press the switch button will stop the machine directly.

When you start the drying function, operating the drying button will stop the inner fans and close the guide louver.

(13) Memory Function

When interrupting the power supply memory content: mode, swing function, light, set temperature and wind speed.

After interrupted the power supply, the machine will start when recovering the power according to the memory content automatically.

7. Installation Manual

7.1 Notices for Installation

- 1.The unit installation work must be done by qualified personnel according to the local rules and this manual.
- 2.Before installing, please contact with local authorized maintenance center, if unit is not installed by the authorized maintenance center, the malfunction may not solved, due to discommodious contacts.
- 3.When removing the unit to the other place, please firstly contact with the authorized Maintenance Center in the local area.
- 4.the appliance must be positioned so that the plug is accessible
- 5.After pull out the power plug then make the appliance operation again,to avoid the icing of outdoor unit damage axial flow fan,should electrify the appliance but not operation for 4 hours for warm-up purpose.

7.1.1 Installation Site Instructions

Install in the following place may cause malfunction. If it is unavoidable contact with service center please:

- strong heat sources, vapours, flammable gas or volatile liquids are emitted.
- high-frequency electro-magnetic waves are generated by radio equipment,welders and medical equipment.
- salt-laden air prevails (such as close to coastal areas).
- the air is contaminated with industrial vapours and oils.
- the air contains sulphures gas such as in hot spring zones.
- corrosion or poor air quality exists.

7.1.2 Installation Site of Indoor Unit

- 1.The air inlet and outlet should be away from the obstructions. Ensure the air can be blown through the whole room.
- 2.Select a site where the condensate can be easily drained out, and where it is easily connected to outdoor unit.
- 3.Select a place where it is out of reach of children.
- 4.Select a place where the wall is strong enough to withstand the full weight and vibration of the unit.
- 5.Be sure to leave enough space to allow access for routine maintenance. The installation site should be 250cm or more above the floor.
- 6.Select a place about 1m or more away from TV set or any other electric appliance.
- 7.Select a place where the filter can be easily taken out.
- 8.Make sure that the indoor unit is installed in accordance with installation dimension instructions.
- 9.Do not use the unit in the laundry or by swimming pool etc.

7.1.3 Installation Site of Outdoor Unit

- 1.Select a site where noise and outflow air emitted by the unit will not annoy neighbors.
- 2.Select a site where there is sufficient ventilation.
- 3.Select a site where there is no obstruction blocking the inlet and outlet.
- 4.The site should be able to withstand the full weight and vibration.
- 5.Select a dry place, but do not expose the unit to direct sunlight or strong wind.
- 6.Make sure that the outdoor unit is installed in accordance with the installation instructions, and is convenient for maintenance and repair.
- 7.The height difference between indoor and outdoor units is within 10m and the length of the connecting tubing does not exceed 15m(09K) or 20m(12K).
- 8.Select a place where it is out of reach of children.
- 9.Select a place where the unit does not have negative impact on pedestrians or on the city.

7.1.4 Safety Precautions for Electric Appliances

1. A dedicated power supply circuit should be used in accordance with local electrical safety regulations.
2. Don't drag the power cord with excessive force.
3. The unit should be reliably earthed and connected to an exclusive earth device by the professionals.
4. The air switch must have the functions of magnetic tripping and heat tripping to prevent short circuit and overload.
5. The minimum distance between the unit and combustive surface is 1.5m.
6. The appliance shall be installed in accordance with national wiring regulations.
7. An all-pole disconnection switch with a contact separation of at least 3mm in all poles should be connected in fixed wiring.


Note:

- Make sure the live wire, neutral wire and earth wire in the family power socket are properly connected.
- There should be reliable circuit in the diagram. Inadequate or incorrect electrical connections may cause electric shock or fire.

7.1.5 Earthing Requirements

1. Air conditioner is type I electric appliance. Please ensure that the unit is reliably earthed.
2. The yellow-green wire in air conditioner is the earthing wire which can not be used for other purposes. Improper earthing may cause electric shock.
3. The earth resistance should accord to the national criterion.
4. The power must have reliable earthing terminal. Please do not connect the earthing wire with the following:
① Water pipe ② Gas pipe ③ Contamination pipe ④ Other place that professional personnel consider is unreliable
5. The model and rated values of fuses should accord with the silk print on fuse cover or related PCB.

7.2 Installation Dimension Diagram




- The dimensions of the space necessary for proper installation of the appliance include the minimum permissible distances to adjacent structures.

7.3 Install Indoor Unit


7.3.1 Installation of Mounting Plate

1. Mounting plate should be installed horizontally. As the water tray's outlet for the indoor unit is two-way type, during installation, the indoor unit should slightly slant to water tray's outlet for smooth drainage of condensate.
2. Fix the mounting plate on the wall with screws.
3. Be sure that the mounting plate has been fixed firmly enough to withstand about 60 kg. Meanwhile, the weight should be evenly shared by each screw.




7.3.2 Drill Piping Hole

1. Slant the piping hole ($\Phi 55$) on the wall slightly downward to the outdoor side.
2. Insert the piping-hole sleeve into the hole to prevent the connection piping and wiring from being damaged when passing through the hole.



7.3.3 Installation of Drain Hose

1. Connect the drain hose to the outlet pipe of the indoor unit. Bind the joint with rubber belt.
 2. Put the drain hose into insulating tube.
 3. Wrap the insulating tube with wide rubber belt to prevent the shift of insulating tube.
- Slant the drain hose downward slightly for smooth drainage of condensate.



Note: The insulating tube should be connected reliably with the sleeve outside the outlet pipe. The drain hose should be slanted downward slightly, without distortion, bulge or fluctuation. Do not put the outlet in the water.

7.3.4 Connecting Indoor and Outdoor Electric Wires

1. Open the front panel.
2. Remove the wiring cover and wire clamp. Make the power connection cord pass through the hole at the back of indoor unit.
3. Connect and fix the power connection cord to the terminal board. (As shown in Fig.2)
4. Fix the power connection cord with wire clamp and reinstall wiring cover.
5. Reinstall the front panel.




Fig 2




NOTE:

All wires between indoor and outdoor units must be connected by the qualified electric contractor.

- Electric wires must be connected correctly. Improper connection may cause malfunction.
- Tighten the terminal screws securely.
- After tightening the screws, pull the wire slightly to confirm whether it is firm or not.
- Make sure that the electric connections are earthed properly to prevent electric shock.
- Make sure that all wiring connections are secure and the cover plates are reinstalled properly. Poor installation may cause fire or electric shock.

7.3.5 Installation of Indoor Unit


- The piping can be output from right, right rear, left or left rear.
1. When routing the piping and wiring from the left or right side of indoor unit, cut off the tailings from the chassis when necessary (As shown in Fig.3)
 - (1) Cut off tailing 1 when routing the wiring only;
 - (2) Cut off tailing 1 and tailing 2 when routing both the wiring and piping.
 2. Take out the piping from body case; wrap the piping, power cords, drain hose with the tape and then make them pass through the piping hole. (As shown in Fig4)
 3. Hang the mounting slots of the indoor unit on the upper hooks of the mounting plate and check if it is firm enough. (As shown in Fig.5)
 4. The installation site should be 250cm or more above the floor.



7.3.6 Installation of Connection Pipe

1. Align the center of the pipe flare with the related valve.
2. Screw in the flare nut by hand and then tighten the nut with spanner and torque wrench by referring to the following:

Hex nut diameter	Tightening torque (N·m)
Φ6.35	15~20
Φ9.52	31~35
Φ12.7	50~55
Φ15.88	60~65
Φ19.05	70~75




NOTE: Connect the connection pipe to indoor unit at first and then to outdoor unit. Handle piping bending with care. Do not damage the connection pipe. Ensure that the joint nut is tightened firmly, otherwise, it may cause leakage.

7.4 Install Outdoor Unit

7.4.1 Electric Wiring

1. Remove the handle on the right side plate of outdoor unit.
2. Take off wire wire clamp. Connect and fix power connection cord to the terminal board. Wiring should fit that of indoor unit.
3. Fix the power connection cord with wire clamp.
4. Confirm if the wires have been fixed properly.
5. Reinstall the handle.



NOTE:

- Incorrect wiring may cause malfunction of spare part.
- After the wire has been fixed, ensure there is free space between the connection and fixing places on the lead wire. Schematic diagram being reference only, please refer to real product for authentic information.

7.4.2 Air Purging and Leakage Test

1. Connect charging hose of manifold valve to charge end of low pressure valve (both high/low pressure valves must be tightly shut).
2. Connect joint of charging hose to vacuum pump.
3. Fully open the handle of Lo manifold valve.
4. Open the vacuum pump for vacuumization. At the beginning, slightly loosen joint nut of low pressure valve to check if there is air coming inside (If noise of vacuum pump has been changed, the reading of multimeter is 0). Then tighten the nut.
5. Keep vacuuming for more than 15mins and make sure the reading of multi-meter is -1.0×10^5 pa (-76cmHg).
6. Fully open high/low pressure valves.
7. Remove charging hose from charging end of low pressure valve.
8. Tighten lid of low pressure valve. (As shown in Fig.6)






Fig.6

7.4.3 Outdoor Condensate Drainage (only for heat pump unit)

During heating operation, the condensate and defrosting water should be drained out reliably through the drain hose. Install the outdoor drain connector in a $\Phi 25$ hole on the base plate and attach the drain hose to the connector so that the waste water formed in the outdoor unit can be drained out. The hole diameter 25 must be plugged.



7.5 Check after Installation and Test Operation

7.5.1 Check after Installation

Items to be checked	Possible malfunction
Has it been fixed firmly?	The unit may drop, shake or emit noise.
Have you done the refrigerant leakage test?	It may cause insufficient cooling(heating) capacity
Is heat insulation sufficient?	It may cause condensation and dripping.
Is water drainage satisfactory?	It may cause condensation and dripping.
Is the voltage in accordance with the rated voltage marked on the nameplate?	It may cause electric malfunction or damage the product.
Is the electric wiring and piping connection installed correctly and securely?	It may cause electric malfunction or damage the part.
Has the unit been connected to a secure earth connection?	It may cause electrical leakage.
Is the power cord specified?	It may cause electric malfunction or damage the part.
Are the inlet and outlet openings blocked?	It may cause insufficient cooling(heating) capacity.
Is the length of connection pipes and refrigerant capacity been recorded?	The refrigerant capacity is not accurate.

7.5.1 Check after Installation

1. Before Operation Test

- (1) Do not switch on power before installation is finished completely.
- (2) Electric wiring must be connected correctly and securely.
- (3) Cut-off valves of the connection pipes should be opened.
- (4) All the impurities such as scraps and thrums must be cleared from the unit.

2. Operation Test Method

- (1) Switch on power and press ON/OFF button on the remote controller to start operation.
- (2) Press MODE button to select the COOL, HEAT (Not available for cooling only unit), FAN to check whether the operation is normal or not.

7.6 Installation and Maintenance of Healthy Filter

7.6.1 Installation of Healthy Filter

1. Lift up the front panel from its two ends, as shown by the arrow direction, and then remove the air filter. (as shown in Fig.a)
2. Attach the healthy filter onto the air filter, (as shown in Fig.b).
3. Install the air filter properly along the arrow direction in Fig.c, and then close the panel .




Fig. a




Fig. b




Fig. c

7.6.2 Cleaning and Maintenance

Remove the healthy filter and reinstall it after cleaning according to the installation instruction. Do not use brush or hard objects to clean the filter. After cleaning, be sure to dry it in the shade.


7.6.3 Service Life

The general service life for the healthy filter is about one year under normal condition. As for silver ion filter, it is ineffective when its surface becomes black (green).

This supplementary instruction is provided for reference to the unit with healthy filter. If the graphics provided herein are different from the actual product, please refer to the actual product. The quantity of healthy filters is based on the actual delivery.

8. Exploded Views and Parts List

8.1 Indoor Unit



NO.	Description	Part Code		Qty
		GWH09RB-K3DNA2C/I	GWH12RB-K3DNA2C/I	
		Product code	Product code	
		CB301N01100	CB301N01200	
1	Front Panel Assy	20022122	20022122	1
2	Display Board	30565137	30565137	1
3	Filter Sub-Assy	1112220403	1112220403	2
4	Screw Cover	242520179	242520179	1
5	Front Case Sub-assy	2001279001	2001279001	1
6	Air Louver 1	1051215603	1051215603	1
7	Air Louver 2	1051215503	1051215503	1
8	Helicoid tongue	2611216302	2611216302	1
9	Left Axile Bush	10512037	10512037	1
10	Rear Case assy	22202467	22202467	1
11	Rubber Plug (Water Tray)	76712012	76712012	1
12	Ring of Bearing	26152022	26152022	1
13	O-Gasket of Cross Fan Bearing	76512203	76512203	1
14	O-Gasket sub-assy of Bearing	76512051	76512051	1
15	Cross Flow Fan	10352017	10352017	1
16	Cold Plasma Generator	/	/	/
17	Evaporator Support	24212091	24212091	1
18	Evaporator Assy	01002610	01002610	1
19	Wall Mounting Frame	01252021	01252021	1
20	Motor Press Plate	26112161	26112161	1
21	Fan Motor	1501208904	1501208904	1
22	Pipe Clamp	2611216401	2611216401	1
23	Drainage hose	0523001401	0523001401	1
24	Step Motor	1521212901	1521212901	1
25	Crank	10582070	10582070	1
26	Guide Louver	1051220301	1051220301	1
27	Axile Bush	10542036	10542036	1
28	Electric Box	2011208201	2011208201	1
29	Terminal Board	42011233	42011233	1
30	Electric Box Cover2	2012207512	2012207512	1
31	Main Board	30148782	30148782	1
32	Shield cover of Electric Box sub-assy	01592073	01592073	1
33	Electric Box Cover1	22242135	22242135	1
34	Jumper	4202300102	4202300104	1
35	Electric Box Assy	20402632	20402632	1
36	Power Cord	400204649	400204649	1
37	Connecting Cable	400204055	400204055	1
38	Ambient Temperature Sensor	390000451	390000451	1
39	Remote Controller	30510125	30510125	1
40	Receiving Window	2243013601	2243013601	1
41	Tube Sensor	390000591	390000591	1
42	Pipe Connection Nut accessories	06320020	06320020	1

The data above are subject to change without notice.

NO.	Description	Part Code		Qty
		GWH09RB-K3DNA3C/I	GWH12RB-K3DNA3C/I	
		Product code		
		CB302N00900	CB302N01000	
1	Front Panel Assy	20012858	20012858	1
2	Display Board	30565137	30565137	1
3	Filter Sub-Assy	1112220403	1112220403	2
4	Screw Cover	24252016	24252016	1
5	Front Case Sub-assy	20012790	20012790	1
6	Air Louver 1	1051215603	1051215603	1
7	Air Louver 2	1051215503	1051215503	1
8	Helicoid tongue	2611216302	2611216302	1
9	Left Axile Bush	10512037	10512037	1
10	Rear Case assy	22202467	22202467	1
11	Rubber Plug (Water Tray)	76712012	76712012	1
12	Ring of Bearing	26152022	26152022	1
13	O-Gasket of Cross Fan Bearing	76512203	76512203	1
14	O-Gasket sub-assy of Bearing	76512051	76512051	1
15	Cross Flow Fan	10352017	10352017	1
16	Cold Plasma Generator	/	/	/
17	Evaporator Support	24212091	24212091	1
18	Evaporator Assy	01002610	01002610	1
19	Wall Mounting Frame	01252021	01252021	1
20	Motor Press Plate	26112161	26112161	1
21	Fan Motor	150120874	150120874	1
22	Pipe Clamp	2611216401	2611216401	1
23	Drainage hose	0523001401	0523001401	1
24	Step Motor	1521212901	1521212901	1
25	Crank	10582070	10582070	1
26	Guide Louver	10512203	10512203	1
27	Axile Bush	10542036	10542036	1
28	Electric Box	2011208201	2011208201	1
29	Terminal Board	42011233	42011233	1
30	Electric Box Cover2	20122075	20122075	1
31	Main Board	30148782	30148782	1
32	Shield cover of Electric Box sub-assy	01592073	01592073	1
33	Electric Box Cover1	22242135	22242135	1
34	Jumper	4202300102	4202300104	1
35	Electric Box Assy	20402447	20402447	1
36	Power Cord	400204649	400204649	1
37	Connecting Cable	400204055	400204055	1
38	Ambient Temperature Sensor	390000451	390000451	1
39	Remote Controller	30510125	30510125	1
40	Receiving Window	2243013601	2243013601	1
41	Tube Sensor	390000591	390000591	1
42	Pipe Connection Nut accessories	06320020	06320020	1

The data above are subject to change without notice.

NO.	Description	Part Code		Qty
		GWH09RB-K3DNA5C/I	GWH12RB-K3DNA5C/I	
		Product code	Product code	
		CB304N00500	CB304N00600	
1	Front Panel Assy	20012948	20012948	1
2	Display Board	30565159	30565159	1
3	Filter Sub-Assy	1112220403	1112220403	2
4	Screw Cover	242520179	242520179	1
5	Front Case Sub-assy	2001279001	2001279001	1
6	Air Louver 1	1051215603	1051215603	1
7	Air Louver 2	1051215503	1051215503	1
8	Helicoid tongue	2611216302	2611216302	1
9	Left Axile Bush	10512037	10512037	1
10	Rear Case assy	22202467	22202467	1
11	Rubber Plug (Water Tray)	76712012	76712012	1
12	Ring of Bearing	26152022	26152022	1
13	O-Gasket of Cross Fan Bearing	76512203	76512203	1
14	O-Gasket sub-assy of Bearing	76512051	76512051	1
15	Cross Flow Fan	10352017	10352017	1
16	Cold Plasma Generator	/	/	/
17	Evaporator Support	24212091	24212091	1
18	Evaporator Assy	01002423	01002423	1
19	Wall Mounting Frame	01252021	01252021	1
20	Motor Press Plate	26112161	26112161	1
21	Fan Motor	1501208904	1501208904	1
22	Pipe Clamp	2611216401	2611216401	1
23	Drainage hose	0523001401	0523001401	1
24	Step Motor	1521212901	1521212901	1
25	Crank	10582070	10582070	1
26	Guide Louver	1051220301	1051220301	1
27	Axile Bush	10542036	10542036	1
28	Electric Box	2011208201	2011208201	1
29	Terminal Board	42011233	42011233	1
30	Electric Box Cover2	2012207512	2012207512	1
31	Main Board	30148781	30148781	1
32	Shield cover of Electric Box sub-assy	01592073	01592073	1
33	Electric Box Cover1	22242135	22242135	1
34	Jumper	4202300102	4202300104	1
35	Electric Box Assy	20402669	20402671	1
36	Power Cord	400204649	400204649	1
37	Connecting Cable	400204055	400204055	0
38	Ambient Temperature Sensor	390000451	390000451	1
39	Remote Controller	30510125	30510125	1
40	Receiving Window	2243013601	2243013601	1
41	Tube Sensor	390000591	390000591	1
42	Pipe Connection Nut accessories	06320020	06320020	1

The data above are subject to change without notice.

NO.	Description	PartCode		Qty
		GWH09RB-K3DNA8C/I	GWH12RB-K3DNA8C/I	
		Product code	Product code	
		CB313N00100	CB313N00200	
1	Front Panel Assy	20022516	20022516	1
2	Display Board	30565234	30565234	1
3	Filter Sub-Assy	1112220403	1112220403	2
4	Screw Cover	24252016	24252016	1
5	Front Case Sub-assy	20012790	20012790	1
6	Air Louver 1	1051215603	1051215603	1
7	Air Louver 2	1051215503	1051215503	1
8	Helicoid tongue	2611216302	2611216302	1
9	Left Axile Bush	10512037	10512037	1
10	Rear Case assy	22202467	22202467	1
11	Rubber Plug (Water Tray)	76712012	76712012	1
12	Ring of Bearing	26152022	26152022	1
13	O-Gasket of Cross Fan Bearing	76512203	76512203	1
14	O-Gasket sub-assy of Bearing	76512051	76512051	1
15	Cross Flow Fan	10352017	10352017	1
16	Cold Plasma Generator	1114001602	1114001602	1
17	Evaporator Support	24212091	24212091	1
18	Evaporator Assy	01002423	01002423	1
19	Wall Mounting Frame	01252021	01252021	1
20	Motor Press Plate	26112161	26112161	1
21	Fan Motor	1501208904	1501208904	1
22	Pipe Clamp	2611216401	2611216401	1
23	Drainage hose	0523001401	0523001401	1
24	Step Motor	1521212901	1521212901	1
25	Crank	10582070	10582070	1
26	Guide Louver	10512203	10512203	1
27	Axile Bush	10542036	10542036	1
28	Electric Box	2011208201	2011208201	1
29	Terminal Board	42011233	42011233	1
30	Electric Box Cover2	20122075	20122075	1
31	Main Board	30148781	30148781	1
32	Shield cover of Electric Box sub-assy	01592073	01592073	1
33	Electric Box Cover1	22242135	22242135	1
34	Jumper	4202300102	4202300104	1
35	Electric Box Assy	20402741	20402754	1
36	Power Cord	400204649	400204649	1
37	Connecting Cable	400204055	400204055	0
38	Ambient Temperature Sensor	390000451	390000451	1
39	Remote Controller	30510125	30510125	1
40	Receiving Window	2243013601	2243013601	1
41	Tube Sensor	390000591	390000591	1
42	Pipe Connection Nut accessories	06320020	06320020	1

The data above are subject to change without notice.

NO.	Description	Part Code		Qty
		GWH09RB-K3DNA2C/I	GWH12RB-K3DNA2C/I	
		Product code	Product code	
		CB301N01100	CB301N01200	
1	Front Panel Assy	20022122	20022122	1
2	Display Board	30565137	30565137	1
3	Filter Sub-Assy	1112220403	1112220403	2
4	Screw Cover	242520179	242520179	1
5	Front Case Sub-assy	2001279001	2001279001	1
6	Air Louver 1	1051215603	1051215603	1
7	Air Louver 2	1051215503	1051215503	1
8	Helicoid tongue	2611216302	2611216302	1
9	Left Axile Bush	10512037	10512037	1
10	Rear Case assy	22202467	22202467	1
11	Rubber Plug (Water Tray)	76712012	76712012	1
12	Ring of Bearing	26152022	26152022	1
13	O-Gasket of Cross Fan Bearing	76512203	76512203	1
14	O-Gasket sub-assy of Bearing	76512051	76512051	1
15	Cross Flow Fan	10352017	10352017	1
16	Cold Plasma Generator	1114001602	1114001602	1
17	Evaporator Support	24212091	24212091	1
18	Evaporator Assy	01002610	01002610	1
19	Wall Mounting Frame	01252021	01252021	1
20	Motor Press Plate	26112161	26112161	1
21	Fan Motor	1501208904	1501208904	1
22	Pipe Clamp	2611216401	2611216401	1
23	Drainage hose	0523001401	0523001401	1
24	Step Motor	1521212901	1521212901	1
25	Crank	10582070	10582070	1
26	Guide Louver	1051220301	1051220301	1
27	Axile Bush	10542036	10542036	1
28	Electric Box	2011208201	2011208201	1
29	Terminal Board	42011233	42011233	1
30	Electric Box Cover2	2012207512	2012207512	1
31	Main Board	30148782	30148782	1
32	Shield cover of Electric Box sub-assy	01592073	01592073	1
33	Electric Box Cover1	22242135	22242135	1
34	Jumper	4202300102	4202300104	1
35	Electric Box Assy	20402632	20402632	1
36	Power Cord	400204649	400204649	1
37	Connecting Cable	400204055	400204055	1
38	Ambient Temperature Sensor	390000451	390000451	1
39	Remote Controller	30510125	30510125	1
40	Receiving Window	2243013601	2243013601	1
41	Tube Sensor	390000591	390000591	1
42	Pipe Connection Nut accessories	06320020	06320020	1

The data above are subject to change without notice.

NO.	Description	Part Code		Qty
		GWH09RB-K3DNA3C/I	GWH12RB-K3DNA3C/I	
		Product code		
		CB302N00900	CB302N01000	
1	Front Panel Assy	20012858	20012858	1
2	Display Board	30565137	30565137	1
3	Filter Sub-Assy	1112220403	1112220403	2
4	Screw Cover	24252016	24252016	1
5	Front Case Sub-assy	20012790	20012790	1
6	Air Louver 1	1051215603	1051215603	1
7	Air Louver 2	1051215503	1051215503	1
8	Helicoid tongue	2611216302	2611216302	1
9	Left Axile Bush	10512037	10512037	1
10	Rear Case assy	22202467	22202467	1
11	Rubber Plug (Water Tray)	76712012	76712012	1
12	Ring of Bearing	26152022	26152022	1
13	O-Gasket of Cross Fan Bearing	76512203	76512203	1
14	O-Gasket sub-assy of Bearing	76512051	76512051	1
15	Cross Flow Fan	10352017	10352017	1
16	Cold Plasma Generator	2611216302	2611216302	1
17	Evaporator Support	24212091	24212091	1
18	Evaporator Assy	01002610	01002610	1
19	Wall Mounting Frame	01252021	01252021	1
20	Motor Press Plate	26112161	26112161	1
21	Fan Motor	150120874	150120874	1
22	Pipe Clamp	2611216401	2611216401	1
23	Drainage hose	0523001401	0523001401	1
24	Step Motor	1521212901	1521212901	1
25	Crank	10582070	10582070	1
26	Guide Louver	10512203	10512203	1
27	Axile Bush	10542036	10542036	1
28	Electric Box	2011208201	2011208201	1
29	Terminal Board	42011233	42011233	1
30	Electric Box Cover2	20122075	20122075	1
31	Main Board	30148782	30148782	1
32	Shield cover of Electric Box sub-assy	01592073	01592073	1
33	Electric Box Cover1	22242135	22242135	1
34	Jumper	4202300102	4202300104	1
35	Electric Box Assy	20402447	20402447	1
36	Power Cord	400204649	400204649	1
37	Connecting Cable	400204055	400204055	1
38	Ambient Temperature Sensor	390000451	390000451	1
39	Remote Controller	30510125	30510125	1
40	Receiving Window	2243013601	2243013601	1
41	Tube Sensor	390000591	390000591	1
42	Pipe Connection Nut accessories	06320020	06320020	1


The data above are subject to change without notice.

NO.	Description	Part Code		Qty
		GWH09RB-K3DNA6C/I	GWH12RB-K3DNA6C/I	
		Product code	Product code	
		CB305N00100	CB305N00200	
1	Front Panel Assy	20022260	20022260	1
2	Display Board	30565207	30565207	1
3	Filter Sub-Assy	1112220403	1112220403	2
4	Screw Cover	242520179	242520179	1
5	Front Case Sub-assy	2001279001	2001279001	1
6	Air Louver 1	1051215603	1051215603	1
7	Air Louver 2	1051215503	1051215503	1
8	Helicoid tongue	2611216302	2611216302	1
9	Left Axile Bush	10512037	10512037	1
10	Rear Case assy	22202467	22202467	1
11	Rubber Plug (Water Tray)	76712012	76712012	1
12	Ring of Bearing	26152022	26152022	1
13	O-Gasket of Cross Fan Bearing	76512203	76512203	1
14	O-Gasket sub-assy of Bearing	76512051	76512051	1
15	Cross Flow Fan	10352017	10352017	1
16	Cold Plasma Generator	1114001602	1114001602	1
17	Evaporator Support	24212091	24212091	1
18	Evaporator Assy	01002423	01002423	1
19	Wall Mounting Frame	01252021	01252021	1
20	Motor Press Plate	26112161	26112161	1
21	Fan Motor	1501208904	1501208904	1
22	Pipe Clamp	2611216401	2611216401	1
23	Drainage hose	0523001401	0523001401	1
24	Step Motor	1521212901	1521212901	1
25	Crank	10582070	10582070	1
26	Guide Louver	1051220301	1051220301	1
27	Axile Bush	10542036	10542036	1
28	Electric Box	2011208201	2011208201	1
29	Terminal Board	42011233	42011233	1
30	Electric Box Cover2	2012207512	2012207512	1
31	Main Board	30148781	30148781	1
32	Shield cover of Electric Box sub-assy	0159207301	0159207301	1
33	Electric Box Cover1	22242135	22242135	1
34	Jumper	4202300102	4202300104	1
35	Electric Box Assy	20403049	20403050	1
36	Power Cord	400204649	400204649	1
37	Connecting Cable	400204055	400204055	1
38	Ambient Temperature Sensor	390000451	390000451	1
39	Remote Controller	30510125	30510125	1
40	Receiving Window	2243013601	2243013601	1
41	Tube Sensor	390000591	390000591	1
42	Pipe Connection Nut accessories	06320020	06320020	1

The data above are subject to change without notice.

8.2 Outdoor Unit


GWH09RB-K3DNA3C/O(CB302W00900), GWH12RB-K3DNA3C/O(CB302W01000)



NO.	Description	Part Code		Qty
		GWH09RB-K3DNA3C/O	GWH12RB-K3DNA3C/O	
		Product Code	Product Code	
		CB302W00900	CB302W01000	
1	Electric Box Assy	02613591	02613588	1
2	Electric Box Sub-Assy	02613590	02613589	1
3	Main Board	30148761	30148762	1
4	Reactor	43130184	43130184	1
5	Terminal Board	42011113	420111041	1
6	Wire Clamp	71010003	71010003	1
7	Front Grill	22413008	22413008	1
8	Front Panel	01533034P	0153303204P	1
9	Axial Flow Fan	10333004	10333004	1
10	Chassis Sub-assy	02803151P	02803216P	1
11	Fan Motor	1501308502	15013085	1
12	Small Handle	26233100	26233100	1
13	Top Cover Sub-Assy	01253073	01253443	1
14	Motor Support	0170310401	0170310201	1
15	Condenser Assy	01163789	01163761	1
16	Rear Grill	01473009	01473057	1
17	Electronic Expansion Valve	07130369	07130369	1
18	Cut off Valve	07133804	071302391	1
19	Big Handle	26233433	26233433	1
20	Valve	07100003	07100003	1
21	Valve Support	0171314201P	07133805	1
22	Right Side Plate Sub-Assy	0130317801	0130317801	1
23	4-Way Valve Assy	03073007	03073117	1
24	Clapboard Sub-Assy	01233385	03073117	1
25	Magnet Coil	4300040050	4300040050	1
26	Compressor and Fittings	00103897G	00103896G	1
27	Drainage Connector	06123401	06123401	1

The data above are subject to change without notice.

GWH09RB-K3DNA3C/O(CB302W00901), GWH12RB-K3DNA3C/O(CB302W01001)




NO.	Description	Part Code		Qty
		GWH09RB-K3DNA3C/O	GWH12RB-K3DNA3C/O	
		Product Code	Product Code	
		CB302W00900	CB302W01000	
1	Electric Box Assy	02613591	02613588	1
2	Electric Box Sub-Assy	02613590	02613589	1
3	Main Board	30148761	30148762	1
4	Reactor	43130184	43130184	1
5	Terminal Board	42011113	420111041	1
6	Wire Clamp	71010003	71010003	1
7	Front Grill	22413027	22413027	1
8	Front Panel	01533034P	0153303204P	1
9	Axial Flow Fan	10333004	10333004	1
10	Chassis Sub-assy	02803151P	02803216P	1
11	Fan Motor	1501308502	15013085	1
12	Small Handle	26233100	26233100	1
13	Top Cover Sub-Assy	01253073	01253443	1
14	Motor Support	0170310401	0170310201	1
15	Condenser Assy	01163789	01163761	1
16	Rear Grill	01473009	01473057	1
17	Electronic Expansion Valve	07130369	07130369	1
18	Cut off Valve	07133804	071302391	1
19	Big Handle	26233433	26233433	1
20	Valve	07100003	07100003	1
21	Valve Support	0171314201P	07133805	1
22	Right Side Plate Sub-Assy	0130317801	0130317801	1
23	4-Way Valve Assy	03073007	03073117	1
24	Clapboard Sub-Assy	01233385	03073117	1
25	Magnet Coil	4300040050	4300040050	1
26	Compressor and Fittings	00103897G	00103896G	1
27	Drainage Connector	06123401	06123401	1


The data above are subject to change without notice.


9. Troubleshooting


9.1 Malfunction Analysis

Note:When replacing the controller, make sure insert the wire jumper into the new controller, otherwise the unit will display C5.









9.2 Flashing LED of Indoor/Outdoor Unit and Primary Judgement

Flashing LED of Indoor/Outdoor Unit and Primary Judgement

NO.	Malfunction Name	Display Method of Indoor Unit			Display Method of Outdoor Unit			A/C status	Possible Causes		
		Dual-8 Code Display	Indicator Display (during blinking, ON 0.5s and OFF 0.5s)	Operation Indicator	Cool Indicator	Heating Indicator	Indicator has 3 kinds of display status and during blinking, ON 0.5s and OFF 0.5s			Yellow Indicator	Red Indicator
1	High pressure protection of system	E1	OFF 3s and blink once							During cooling and drying operation, except indoor fan operates, all loads stop operation. During heating operation, the complete unit stops.	Possible reasons: 1. Refrigerant was superabundant; 2. Poor heat exchange (including filth blockage of heat exchanger and bad radiating environment); Ambient temperature is too high.
2	Antifreezing protection	E2	OFF 3S and blink twice				OFF 1S and blink 3 times			During cooling and drying operation, compressor and outdoor fan stop while indoor fan operates.	1. Poor air-return in indoor unit; 2. Fan speed is abnormal; 3. Evaporator is dirty.
3	Refrigerant leakage protection	F0						OFF 1S and blink 9 times		The Dual-8 Code Display will show F0 and the complete unit stops.	1.Refrigerant leakage; 2.Indoor evaporator temperature sensor works abnormally; 3.The unit has been plugged up somewhere.
4	High discharge temperature protection of compressor	E4	OFF 3S and blink 4 times				OFF 1S and blink 7 times			During cooling and drying operation, compressor and outdoor fan stop while indoor fan operates. During heating operation, all loads stop.	Please refer to the malfunction analysis (discharge protection, overload).
5	Overcurrent protection	E5	OFF 3S and blink 5 times				OFF 1S and blink 5 times			During cooling and drying operation, compressor and outdoor fan stop while indoor fan operates. During heating operation, all loads stop.	1. Supply voltage is unstable; 2. Supply voltage is too low and load is too high; 3. Evaporator is dirty.
6	Communication Malfunction	E6	OFF 3S and blink 6 times				Always ON			During cooling operation, compressor stops while indoor fan motor operates. During heating operation, the complete unit stops.	Refer to the corresponding malfunction analysis.
7	High temperature resistant protection	E8	OFF 3S and blink 8 times				OFF 1S and blink 6 times			During cooling operation: compressor will stop while indoor fan will operate. During heating operation, the complete unit stops.	Refer to the malfunction analysis (overload, high temperature resistant).
8	EEPROM malfunction	EE			OFF 3S and blink 15 times		OFF 1S and blink 11 times			During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop	Replace outdoor control panel AP1
9	Limit/ decrease frequency due to high temperature of module	EU		OFF 3S and blink 6 times		OFF 3S and blink 6 times				All loads operate normally, while operation frequency for compressor is decreased	Discharging after the complete unit is de-energized for 20mins, check whether the thermal grease on IPM Module of outdoor control panel AP1 is sufficient and whether the radiator is inserted tightly. If its no use, please replace control panel AP1.
10	Malfunction protection of jumper cap	C5	OFF 3S and blink 15 times							Wireless remote receiver and button are effective, but can not dispose the related command	1. No jumper cap insert on mainboard. 2. Incorrect insert of jumper cap. 3. Jumper cap damaged. 4. Abnormal detecting circuit of mainboard.

NO.	Malfunction Name	Display Method of Indoor Unit			Display Method of Outdoor Unit			A/C status	Possible Causes	
		Dual-8 Code Display	Indicator Display (during blinking, ON 0.5s and OFF 0.5s)			Indicator has 3 kinds of display status and during blinking, ON 0.5s and OFF 0.5s				
			Operation Indicator	Cool Indicator	Heating Indicator	Yellow Indicator	Red Indicator			Green Indicator
11	Gathering refrigerant	Fo	OFF 3S and blink 1 times	OFF 3S and blink 1 times		OFF 1S and blink 17 times			When the outdoor unit receive signal of Gathering refrigerant ,the system will be forced to run under cooling mode for gathering refrigerant	Nominal cooling mode
12	Indoor ambient temperature sensor is open/short circuited	F1		OFF 3S and blink once					During cooling and drying operation, indoor unit operates while other loads will stop; during heating operation, the complete unit will stop operation.	1. Loosening or bad contact of indoor ambient temp. sensor and mainboard terminal. 2. Components in mainboard fell down leads short circuit. 3. Indoor ambient temp. sensor damaged.(check with sensor resistance value chart) 4. Mainboard damaged.
13	Indoor evaporator temperature sensor is open/short circuited	F2		OFF 3S and blink twice					AC stops operation once reaches the setting temperature. Cooling, drying: internal fan motor stops operation while other loads stop operation; heating: AC stop operation	1. Loosening or bad contact of Indoor evaporator temp. sensor and mainboard terminal. 2. Components on the mainboard fall down leads short circuit. 3. Indoor evaporator temp. sensor damaged.(check temp. sensor value chart for testing) 4. Mainboard damaged.
14	Outdoor ambient temperature sensor is open/short circuited	F3		OFF 3S and blink 3 times			OFF 1S and blink 6 times		During cooling and drying operating, compressor stops while indoor fan operates; During heating operation, the complete unit will stop operation	Outdoor temperature sensor hasnt been connected well or is damaged. Please check it by referring to the resistance table for temperature sensor)
15	Outdoor condenser temperature sensor is open/short circuited	F4		OFF 3S and blink 4 times			OFF 1S and blink 5 times		During cooling and drying operation, compressor stops while indoor fan will operate; During heating operation, the complete unit will stop operation.	Outdoor temperature sensor hasnt been connected well or is damaged. Please check it by referring to the resistance table for temperature sensor)
16	Outdoor discharge temperature sensor is open/short circuited	F5		OFF 3S and blink 5 times			OFF 1S and blink 7 times		During cooling and drying operation, compressor will sop after operating for about 3 mins, while indoor fan will operate; During heating operation, the complete unit will stop after operating for about 3 mins.	1.Outdoor temperature sensor hasnt been connected well or is damaged. Please check it by referring to the resistance table for temperature sensor) 2.The head of temperature sensor hasnt been inserted into the copper tube
17	Limit/ decrease frequency due to overload	F6		OFF 3S and blink for 6 times			OFF 1S and blink 3 times		All loads operate normally, while operation frequency for compressor is decreased	Refer to the malfunction analysis (overload, high temperature resistant)
18	Decrease frequency due to overcurrent	F8		OFF 3S and blink 8 times			OFF 1S and blink once		All loads operate normally, while operation frequency for compressor is decreased	The input supply voltage is too low; System pressure is too high and overload

NO.	Malfunction Name	Display Method of Indoor Unit			Display Method of Outdoor Unit			A/C status	Possible Causes	
		Dual-8 Code Display	Indicator Display (during blinking, ON 0.5s and OFF 0.5s)			Indicator has 3 kinds of display status and during blinking, ON 0.5s and OFF 0.5s				
			Operation Indicator	Cool Indicator	Heating Indicator	Yellow Indicator	Red Indicator			Green Indicator
19	Decrease frequency due to high air discharge	F9		OFF 3S and blink 9 times				OFF 1S and blink twice	All loads operate normally, while operation frequency for compressor is decreased	Overload or temperature is too high; Refrigerant is insufficient; Malfunction of electric expansion valve (EKV)
20	Limit/ decrease frequency due to antifreezing	FH		OFF 3S and blink 2 times	OFF 3S and blink 2 times			OFF 1S and blink 4 times	All loads operate normally, while operation frequency for compressor is decreased	Poor air-return in indoor unit or fan speed is too low
21	Voltage for DC bus-bar is too high	PH		OFF 3S and blink 11 times				OFF 1S and blink 13 times	During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop operation.	1. Measure the voltage of position L and N on wiring board (XT), if the voltage is higher than 265VAC, turn on the unit after the supply voltage is increased to the normal range. 2.If the AC input is normal, measure the voltage of electrolytic capacitor C on control panel (AP1), if its normal, theres malfunction for the circuit, please replace the control panel (AP1)
22	Voltage of DC bus-bar is too low	PL			OFF 3S and blink 21 times			OFF 1S and blink 12 times	During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop	1. Measure the voltage of position L and N on wiring board (XT), if the voltage is higher than 150VAC, turn on the unit after the supply voltage is increased to the normal range. 2.If the AC input is normal, measure the voltage of electrolytic capacitor C on control panel (AP1), if its normal, theres malfunction for the circuit, please replace the control panel (AP1)
23	Compressor Min frequency in test state	P0		(during blinking, ON 0.25s and OFF 0.25s)	(during blinking, ON 0.25s and OFF 0.25s)					Showing during min. cooling or min. heating test
24	Compresso r rated frequency in test state	P1		(during blinking, ON 0.25s and OFF 0.25s)	(during blinking, ON 0.25s and OFF 0.25s)					Showing during nominal cooling or nominal heating test
25	Compressor maximum frequency in test state	P2		(during blinking, ON 0.25s and OFF 0.25s)	(during blinking, ON 0.25s and OFF 0.25s)					Showing during max. cooling or max. heating test

NO.	Malfunction Name	Display Method of Indoor Unit			Display Method of Outdoor Unit			A/C status	Possible Causes	
		Dual-8 Code Display	Indicator Display (during blinking, ON 0.5s and OFF 0.5s)			Indicator has 3 kinds of display status and during blinking, ON 0.5s and OFF 0.5s				
			Operation Indicator	Cool Indicator	Heating Indicator	Yellow Indicator	Red Indicator			Green Indicator
26	Compressor intermediate frequency in test state	P3		(during blinking, ON 0.25s and OFF 0.25s)	(during blinking, ON 0.25s and OFF 0.25s)				Showing during middle cooling or middle heating test	
27	Overcurrent protection of phase current for compressor	P5		OFF 3S and blink 15 times				During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop operation.	Refer to the malfunction analysis (IPM protection, loss of synchronism protection and overcurrent protection of phase current for compressor.	
28	Charging malfunction of capacitor	PU			OFF 3S and blink 17 times			During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop	Refer to the part three—charging malfunction analysis of capacitor	
29	Malfunction of module temperature sensor circuit	P7			OFF 3S and blink 18 times			During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop	Replace outdoor control panel AP1	
30	Module high temperature protection	P8			OFF 3S and blink 19 times			During cooling operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop	After the complete unit is de-energized for 20mins, check whether the thermal grease on IPM Module of outdoor control panel AP1 is sufficient and whether the radiator is inserted tightly. If its no use, please replace control panel AP1.	
31	Decrease frequency due to high temperature resistant during heating operation	H0			OFF 3S and blink 10 times			All loads operate normally, while operation frequency for compressor is decreased	Refer to the malfunction analysis (overload, high temperature resistant)	
32	Static dedusting protection	H2			OFF 3S and blink twice					
33	Overload protection for compressor	H3			OFF 3S and blink 3 times	OFF 1S and blink 8 times		During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop operation.	1. Wiring terminal OVC-COMP is loosened. In normal state, the resistance for this terminal should be less than 1ohm. 2.Refer to the malfunction analysis (discharge protection, overload)	

NO.	Malfunction Name	Display Method of Indoor Unit			Display Method of Outdoor Unit			A/C status	Possible Causes	
		Dual-8 Code Display	Indicator Display (during blinking, ON 0.5s and OFF 0.5s)			Indicator has 3 kinds of display status and during blinking, ON 0.5s and OFF 0.5s				
			Operation Indicator	Cool Indicator	Heating Indicator	Yellow Indicator	Red Indicator			Green Indicator
34	System is abnormal	H4			OFF 3S and blink 4 times	OFF 1S and blink 6 times			During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop operation. Refer to the malfunction analysis (overload, high temperature resistant)	
35	IPM protection	H5			OFF 3S and blink 5 times	OFF 1S and blink 4 times			During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop operation. Refer to the malfunction analysis (IPM protection, loss of synchronism protection and overcurrent protection of phase current for compressor.	
36	Module temperature is too high	H5			OFF 3S and blink 5 times	OFF 1S and blink 10 times				
37	Internal motor (fan motor) do not operate	H6	OFF 3S and blink 11 times					Internal fan motor, external fan motor, compressor and electric heater stop operation,guide louver stops at present location.	1. Bad contact of DC motor feedback terminal. 2. Bad contact of DC motor control end. 3. Fan motor is stalling. 4. Motor malfunction. 5. Malfunction of mainboard rev detecting circuit.	
38	Desynchronizing of compressor	H7			OFF 3S and blink 7 times			During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop operation. Refer to the malfunction analysis (IPM protection, loss of synchronism protection and overcurrent protection of phase current for compressor.		
39	PFC protection	HC			OFF 3S and blink 6 times	OFF 1S and blink 14 times		During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop operation. Refer to the malfunction analysis		
40	Outdoor DC fan motor malfunction	L3	OFF 3S and blink 23 times				OFF 1S and blink 14 times	Outdoor DC fan motor malfunction lead to compressor stop operation,	DC fan motor malfunction or system blocked or the connector loosed	
41	power protection	L9	OFF 3S and blink 20 times			OFF 1S and blink 9 times		compressor stop operation and Outdoor fan motor will stop 30s latter , 3 minutes latter fan motor and compressor will restart	To protect the electrical components when detect high power	
42	Indoor unit and outdoor unit doesn't match	LP	OFF 3S and blink 19 times			OFF 1S and blink 16 times		compressor and Outdoor fan motor can't work	Indoor unit and outdoor unit doesn't match	
43	Failure start-up	LC			OFF 3S and blink 11 times			During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop operation. Refer to the malfunction analysis		

NO.	Malfunction Name	Display Method of Indoor Unit			Display Method of Outdoor Unit			A/C status	Possible Causes	
		Dual-8 Code Display	Indicator Display (during blinking, ON 0.5s and OFF 0.5s)			Indicator has 3 kinds of display status and during blinking, ON 0.5s and OFF 0.5s				
			Operation Indicator	Cool Indicator	Heating Indicator	Yellow Indicator	Red Indicator			Green Indicator
44	Malfunction of phase current detection circuit for compressor	U1			OFF 3S and blink 13 times				During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop	Replace outdoor control panel AP1
45	Malfunction of voltage dropping for DC bus-bar	U3			OFF 3S and blink 20 times				During cooling and drying operation, compressor will stop while indoor fan will operate; During heating operation, the complete unit will stop	Supply voltage is unstable
46	Malfunction of complete units current detection	U5			OFF 3S and blink 13 times				During cooling and drying operation, the compressor will stop while indoor fan will operate; During heating operating, the complete unit will stop operation.	Theres circuit malfunction on outdoor units control panel AP1, please replace the outdoor units control panel AP1.
47	The four-way valve is abnormal	U7			OFF 3S and blink 20 times				If this malfunction occurs during heating operation, the complete unit will stop operation.	1. Supply voltage is lower than AC175V; 2. Wiring terminal 4V is loosened or broken; 3. 4V is damaged, please replace 4V.
48	Zero-crossing malfunction of outdoor unit	U9	OFF 3S and blink 18 times						During cooling operation, compressor will stop while indoor fan will operate; during heating, the complete unit will stop operation.	Replace outdoor control panel AP1
49	Frequency limiting (power)						OFF 1S and blink 13 times			
50	Compressor running					OFF 1S and blink once				
51	The temperature for turning on the unit is reached						OFF 1S and blink 8 times			
52	Frequency limiting (module temperature)						OFF 1S and blink 11 times			

NO.	Malfunction Name	Display Method of Indoor Unit			Display Method of Outdoor Unit			A/C status	Possible Causes	
		Dual-8 Code Display	Indicator Display (during blinking, ON 0.5s and OFF 0.5s)			Indicator has 3 kinds of display status and during blinking, ON 0.5s and OFF 0.5s				
			Operation Indicator	Cool Indicator	Heating Indicator	Yellow Indicator	Red Indicator	Green Indicator		
53	Normal communication							OFF 0.5S and blink once		
54	Defrosting				OFF 3S and blink once (during blinking, ON 10s and OFF 0.5s)	OFF 1S and blink twice			Defrosting will occur in heating mode. Compressor will operate while indoor fan will stop operation.	Its the normal state


9.3 How to Check Simply the Main Part

(1) Capacitor charge fault (Fault with outdoor unit) (AP1 below refers to the outdoor control panel)

Main Check Points:

Use AC voltmeter to check if the voltage between terminal L and N on the wiring board is within 210VAC~240VAC. If the reactor (L) is correctly connected? If the connection is loose or fallen? If the reactor (L) is damaged?

Fault diagnosis process:




(3) High temperature and overload protection diagnosis (AP1 here in after refers to the control board of the outdoor unit)

Mainly detect:

Is outdoor ambient temperature in normal range?

After the outdoor and indoor fans operating normally?

Is the heat dissipation environment inside and outside the unit is good?




(4) Start-up failure(following AP1 for outdoor unit control board)

Mainly detect:

Whether the compressor wiring is connected correct?

Is time for compressor stopping enough?

Is compressor broken?




(5) Out of step diagnosis for the compressor (AP1 hereinafter refers to the control board of the outdoor unit)

Main detect:

Whether the system pressure is too high?

Whether the input voltage is too low?




(6) Overload and air exhaust malfunction diagnosis (following AP1 for outdoor unit control board)


Mainly detect:

Whether the PMV is connected well or not? Is PMV damaged?

Is refrigerant leaked?



(7) Power factor correct or (PFC) fault (a fault of outdoor unit)(AP1 here in after refers to the control board of the outdoor unit)



(8) Communication malfunction:(following AP1 for outdoor unit control board)

Mainly detect:

Detect the indoor and outdoor units connection wire and indoor and outdoor units inside wiring is connect well or not, If is there any damage?

Is there any damage for the indoor unit mainboard communication circuit? Is communication circuit damaged?

The flow chart fir malfunction detect:



Appendix

Appendix 1: Resistance Table of Ambient Temperature Sensor for Indoor and Outdoor Units(15K)							
Temp. (°C)	Resistance(kΩ)	Temp. (°C)	Resistance(kΩ)	Temp. (°C)	Resistance(kΩ)	Temp. (°C)	Resistance(kΩ)
-19	138.1	20	18.75	59	3.848	98	1.071
-18	128.6	21	17.93	60	3.711	99	1.039
-17	121.6	22	17.14	61	3.579	100	1.009
-16	115	23	16.39	62	3.454	101	0.98
-15	108.7	24	15.68	63	3.333	102	0.952
-14	102.9	25	15	64	3.217	103	0.925
-13	97.4	26	14.36	65	3.105	104	0.898
-12	92.22	27	13.74	66	2.998	105	0.873
-11	87.35	28	13.16	67	2.896	106	0.848
-10	82.75	29	12.6	68	2.797	107	0.825
-9	78.43	30	12.07	69	2.702	108	0.802
-8	74.35	31	11.57	70	2.611	109	0.779
-7	70.5	32	11.09	71	2.523	110	0.758
-6	66.88	33	10.63	72	2.439	111	0.737
-5	63.46	34	10.2	73	2.358	112	0.717
-4	60.23	35	9.779	74	2.28	113	0.697
-3	57.18	36	9.382	75	2.206	114	0.678
-2	54.31	37	9.003	76	2.133	115	0.66
-1	51.59	38	8.642	77	2.064	116	0.642
0	49.02	39	8.297	78	1.997	117	0.625
1	46.6	40	7.967	79	1.933	118	0.608
2	44.31	41	7.653	80	1.871	119	0.592
3	42.14	42	7.352	81	1.811	120	0.577
4	40.09	43	7.065	82	1.754	121	0.561
5	38.15	44	6.791	83	1.699	122	0.547
6	36.32	45	6.529	84	1.645	123	0.532
7	34.58	46	6.278	85	1.594	124	0.519
8	32.94	47	6.038	86	1.544	125	0.505
9	31.38	48	5.809	87	1.497	126	0.492
10	29.9	49	5.589	88	1.451	127	0.48
11	28.51	50	5.379	89	1.408	128	0.467
12	27.18	51	5.197	90	1.363	129	0.456
13	25.92	52	4.986	91	1.322	130	0.444
14	24.73	53	4.802	92	1.282	131	0.433
15	23.6	54	4.625	93	1.244	132	0.422
16	22.53	55	4.456	94	1.207	133	0.412
17	21.51	56	4.294	95	1.171	134	0.401
18	20.54	57	4.139	96	1.136	135	0.391
19	19.63	58	3.99	97	1.103	136	0.382


Appendix 2: Resistance Table of Outdoor and Indoor Tube Temperature Sensors(20K)							
Temp. (°C)	Resistance(kΩ)	Temp. (°C)	Resistance(kΩ)	Temp. (°C)	Resistance(kΩ)	Temp. (°C)	Resistance(kΩ)
-19	181.4	20	25.01	59	5.13	98	1.427
-18	171.4	21	23.9	60	4.948	99	1.386
-17	162.1	22	22.85	61	4.773	100	1.346
-16	153.3	23	21.85	62	4.605	101	1.307
-15	145	24	20.9	63	4.443	102	1.269
-14	137.2	25	20	64	4.289	103	1.233
-13	129.9	26	19.14	65	4.14	104	1.198
-12	123	27	18.13	66	3.998	105	1.164
-11	116.5	28	17.55	67	3.861	106	1.131
-10	110.3	29	16.8	68	3.729	107	1.099
-9	104.6	30	16.1	69	3.603	108	1.069
-8	99.13	31	15.43	70	3.481	109	1.039
-7	94	32	14.79	71	3.364	110	1.01
-6	89.17	33	14.18	72	3.252	111	0.983
-5	84.61	34	13.59	73	3.144	112	0.956
-4	80.31	35	13.04	74	3.04	113	0.93
-3	76.24	36	12.51	75	2.94	114	0.904
-2	72.41	37	12	76	2.844	115	0.88
-1	68.79	38	11.52	77	2.752	116	0.856
0	65.37	39	11.06	78	2.663	117	0.833
1	62.13	40	10.62	79	2.577	118	0.811
2	59.08	41	10.2	80	2.495	119	0.77
3	56.19	42	9.803	81	2.415	120	0.769
4	53.46	43	9.42	82	2.339	121	0.746
5	50.87	44	9.054	83	2.265	122	0.729
6	48.42	45	8.705	84	2.194	123	0.71
7	46.11	46	8.37	85	2.125	124	0.692
8	43.92	47	8.051	86	2.059	125	0.674
9	41.84	48	7.745	87	1.996	126	0.658
10	39.87	49	7.453	88	1.934	127	0.64
11	38.01	50	7.173	89	1.875	128	0.623
12	36.24	51	6.905	90	1.818	129	0.607
13	34.57	52	6.648	91	1.736	130	0.592
14	32.98	53	6.403	92	1.71	131	0.577
15	31.47	54	6.167	93	1.658	132	0.563
16	30.04	55	5.942	94	1.609	133	0.549
17	28.68	56	5.726	95	1.561	134	0.535
18	27.39	57	5.519	96	1.515	135	0.521
19	26.17	58	5.32	97	1.47	136	0.509

Appendix 3: Resistance Table of Outdoor Discharge Temperature Sensor(50K)							
Temp. (°C)	Resistance(kΩ)	Temp. (°C)	Resistance(kΩ)	Temp. (°C)	Resistance(kΩ)	Temp. (°C)	Resistance(kΩ)
-29	853.5	10	98	49	18.34	88	4.754
-28	799.8	11	93.42	50	17.65	89	4.609
-27	750	12	89.07	51	16.99	90	4.469
-26	703.8	13	84.95	52	16.36	91	4.334
-25	660.8	14	81.05	53	15.75	92	4.204
-24	620.8	15	77.35	54	15.17	93	4.079
-23	580.6	16	73.83	55	14.62	94	3.958
-22	548.9	17	70.5	56	14.09	95	3.841
-21	516.6	18	67.34	57	13.58	96	3.728
-20	486.5	19	64.33	58	13.09	97	3.619
-19	458.3	20	61.48	59	12.62	98	3.514
-18	432	21	58.77	60	12.17	99	3.413
-17	407.4	22	56.19	61	11.74	100	3.315
-16	384.5	23	53.74	62	11.32	101	3.22
-15	362.9	24	51.41	63	10.93	102	3.129
-14	342.8	25	49.19	64	10.54	103	3.04
-13	323.9	26	47.08	65	10.18	104	2.955
-12	306.2	27	45.07	66	9.827	105	2.872
-11	289.6	28	43.16	67	9.489	106	2.792
-10	274	29	41.34	68	9.165	107	2.715
-9	259.3	30	39.61	69	8.854	108	2.64
-8	245.6	31	37.96	70	8.555	109	2.568
-7	232.6	32	36.38	71	8.268	110	2.498
-6	220.5	33	34.88	72	7.991	111	2.431
-5	209	34	33.45	73	7.726	112	2.365
-4	198.3	35	32.09	74	7.47	113	2.302
-3	199.1	36	30.79	75	7.224	114	2.241
-2	178.5	37	29.54	76	6.998	115	2.182
-1	169.5	38	28.36	77	6.761	116	2.124
0	161	39	27.23	78	6.542	117	2.069
1	153	40	26.15	79	6.331	118	2.015
2	145.4	41	25.11	80	6.129	119	1.963
3	138.3	42	24.13	81	5.933	120	1.912
4	131.5	43	23.19	82	5.746	121	1.863
5	125.1	44	22.29	83	5.565	122	1.816
6	119.1	45	21.43	84	5.39	123	1.77
7	113.4	46	20.6	85	5.222	124	1.725
8	108	47	19.81	86	5.06	125	1.682
9	102.8	48	19.06	87	4.904	126	1.64





Note: The information above is for reference only.




10. Removal Procedure





10.1 Removal Procedure of Indoor Unit






 **Warning** Be sure to wait for a minimum of 10 minutes after turning off all power supplies before disassembly.






Take A3 panel example.

Steps	Procedure
1. Before disassembly of the unit	
2. Remove filter and horizontal louver	<div style="display: flex; flex-direction: column;"> <div style="display: flex; align-items: center; margin-bottom: 20px;"> <div style="width: 50px; text-align: center;">1</div> <div style="padding-left: 20px;">Open the panel.</div> <div style="width: 400px; height: 100px;">  </div> </div> <div style="display: flex; align-items: center; margin-bottom: 20px;"> <div style="width: 50px; text-align: center;">2</div> <div style="padding-left: 20px;">Loosen clasps on filter and then remove the filter.</div> <div style="width: 400px; height: 100px;">  </div> </div> <div style="display: flex; align-items: center;"> <div style="width: 50px; text-align: center;">3</div> <div style="padding-left: 20px;">Remove axial bush on horizontal louver, and bend the horizontal louver slightly to remove it.</div> <div style="width: 400px; height: 100px;">  </div> </div> </div>


Steps	Procedure	
3. Remove display and panel		
1	Remove screws on display and then remove the display.	
2	Quit the rotation shaft of panel from groove, and then remove the panel.	
4. Remove electric box cover 2		
	Remove screws connecting electric box cover 2 and front case, and then remove the electric box cover 2.	

Steps	Procedure	Procedure
5. Remove front case		
1	Remove screws connecting front case and bottom case.	
2	Open screw cover by hand, remove other 3 screws, loosen clasps connecting front case and bottom case and then remove the front case.	
6. Remove swing blade		
1	Remove 10 clasps connecting swing blade and bottom case.	
2	Remove swing blade.	



Steps	Procedure	
<p>7. Remove electric box</p>		
<p>1</p>	<p>Pull out the indoor temperature sensor.</p>	 <p>indoor temperature sensor</p>
<p>2</p>	<p>Remove screws connecting electric box and bottom case, loosen clasps, remove screws connecting earthing wire and evaporator, and then remove the electric box.</p>	 <p>electric box cover</p>  <p>electric box</p>
<p>8. Remove evaporator</p>		
<p>1</p>	<p>Turn over bottom case, remove screws connecting pipe clamp and bottom case, loosen clasps between connecting pipe clamp and bottom case, and then remove the connecting pipe clamp.</p>	 <p>pipe clamp</p> <p>auxiliary piping</p>
<p>2</p>	<p>Remove screws connecting evaporator and motor press plate and bottom case, loosen clasps fixing evaporator and bottom case, adjust the pipeline and then remove the evaporator.</p>	 <p>evaporator</p>




Steps	Procedure	
9. Remove cross flow blade and motor		
1	Remove screws on stepping motor, and then remove the stepping motor.	 <p>stepping motor</p>
2	Remove 4 screws connecting motor press plate and bottom case, and then remove motor press plate.	 <p>motor press plate</p>
3	Remove cross flow blade and motor.	
4	Remove shaft rubber cushion block.	<p>O-Gasket sub-assy of Bearing</p>  <p>ring of bearing</p>
5	Remove screws connecting cross flow blade and motor shaft, and then remove motor.	 <p>cross flow blade fan mtor</p>




10.2 Removal Procedure of Outdoor Unit



 **Warning** Be sure to wait for a minimum of 10 minutes after turning off all power supplies before disassembly.

Take GWH09RB-K3DNA3C/O(CB302W00900), GWH12RB-K3DNA3C/O(CB302W01000) for example.



Steps	Procedure
<p>1. Remove big handle</p> <p>1 Before disassembly</p> <p>2 Remove 1 connection screw fixing big hand leand then remove the big handle.</p>	
<p>2. Remove top cover plate</p>	<p>Remove 3 connection screws among top cover plate, front panel and right sideplate. Then remove top cover plate.</p> 

Steps	Procedure	
3. Remove front grill and front panel		
4. Remove axial flow fan blade	<p>1 Remove 2 connection screws between front grill and front panel. Then remove front panel.</p> <p>2 Remove 5 connection screws among front panel, chassis and motor support. Then remove front panel.</p>	
5. Remove right side plate	<p>Remove nut of fan blade, and then remove axial flow fan blade.</p>	

Steps	Procedure	
6. Remove electric box assy	<p>Remove the 2 screws fixing the cover of electric box. Lift to remove the cover. Loosen the wire and disconnect the terminal. Lift to remove the electric box assy.</p>	 <p>The diagram shows a 3D perspective view of the main unit with the electric box assembly being removed. A callout line points to the 'Electric box assy' which is shown in two parts: the main box and its cover. The main unit includes a compressor, condenser, and evaporator coils.</p>
7. Disassemble 4-way Valve Assy	<p>Unscrew the fastening nut of the 4-way Valve Assy coil and remove the coil. Wrap the 4-way Valve Assy with wet cotton and unsolder the 4 weld spots connecting the 4-way Valve Assy to take it out. (Note: Refrigerant should be discharged firstly.) Welding process should be as quickly as possible and keep wrapping cotton wet all the time. Be sure not to burn out the lead-out wire of compressor.</p>	 <p>The diagram shows the 4-way Valve Assy being removed from the main unit. A callout line points to the '4-way Valve Assy' which is shown in two parts: the main valve assembly and its coil. The main unit includes a compressor, condenser, and evaporator coils.</p>
8. Disassemble Capillary Sub-assy	<p>Unsolder weld point of capillary Sub-assy, valve and outlet pipe of condensator. Then remove the capillary Sub-assy. Do not block the capillary when unsoldering it. (Note: before unsoldering, discharge refrigerants completely)</p>	 <p>The diagram shows the Capillary Sub-assy being removed from the main unit. A callout line points to the 'Capillary Sub-assy' which is shown in two parts: the main sub-assembly and its valve. The main unit includes a compressor, condenser, and evaporator coils.</p>

Steps	Procedure
9. Disassemble motor and motor support	<p data-bbox="217 465 715 636">Remove the 4 tapping screws fixing the motor. Pull out the lead-out wire and remove the motor. Remove the 2 tapping screws fixing the motor support. Lift motor support to remove it.</p>  <p data-bbox="821 383 1011 551">Motor support Motor</p>
10. Disassemble Clapboard Sub-Assy	<p data-bbox="217 1106 730 1240">Loosen the screws of the Clapboard Sub-Assy . The Clapboard Sub-Assy has a hook on the lower side. Lift and pull the Clapboard Sub-Assy to remove.</p>  <p data-bbox="855 976 1102 1010">Clapboard Sub-Assy</p>

Steps	Procedure
11. Disassemble Compressor	
1	<p>Remove the 2 screws fixing the gas valve. Unsolder the welding spot connecting gas valve and air return pipe and remove the gas valve. (Note: it is necessary to warp the gas valve when unsoldering the welding spot.) Remove the 2 screws fixing liquid valve. Unsolder the welding spot connecting liquid valve and remove the liquid valve.</p>
2	<p>Remove the 3 footing screws of the compressor and remove the compressor.</p>



JF00301769

GREE ELECTRIC APPLIANCES, INC. OF ZHUHAI

Add: West Jinji Rd, Qianshan, Zhuhai, Guangdong, China, 519070

Tel: (+86-756) 8522218 Fax: (+86-756) 8669426

E-mail: gree@gree.com.cn www.gree.com

For continuous improvement in the products, Gree reserves the right to modify the product specification and appearance in this manual without notice and without incurring any obligations.